

DIGIFLEX SECURITY ELECTRONICS

Installer Reference Guide

Issue 1.10



VISION-XIP

Security Controller

N12138 N12138 TELEPERMIT CE RoHS

Copyright Notice

Unless otherwise indicated, this publication is the copyright of Digiflex Pty Ltd ("Digiflex"). All rights are reserved. You may download a single copy of this publication. By downloading the publication you agree that you will: (i) only use the publication for your own reference; (ii) not commercially exploit or charge any person for the use of the publication; and (iii) not modify the publication in any way without the prior written permission of Digiflex. Except as specified above or where authorised by the Copyright Act 1968 (Cth), no part of this publication may be reproduced, transmitted, modified or stored in any form or by any means, without the prior written permission of Digiflex.

Trademarks

Throughout this document trademark names may have been used. Rather than put a trademark symbol in every occurrence of a trademark name, we state that we are using the names only in an editorial fashion and to the benefit of the trademark owner with no intention of infringement of the trademark.

Notice of Liability

While every effort has been taken the accuracy of this document, neither Digiflex Pty Ltd nor any of its official representatives shall have any liability to any person or entity with respect to any liability, loss or damage caused or alleged to be caused directly or indirectly by the information contained in this book. Should you find any error on inconsistency, please notify us accordingly.

Digiflex Pty Ltd reserves the right to make changes to features and specifications at any time without prior notification in the interest of ongoing product development and improvement.

Telepermit Note

The grant of a Telepermit for a device in no way indicates Telecom acceptance of responsibility for the correct operation of that device under all operating conditions.

This equipment shall not be used in any manner that could constitute a nuisance to other Telecom customers.

Immediately disconnect this equipment should it become physically damaged, and arrange for its disposal or repair.

The transmit level from this device is set as a fixed level and because of this there may be circumstances where the performance is less than optimal. Before reporting such occurrences as faults, please check the line with a standard telepermitted telephone.

Warnings

1. This product must be installed by a qualified and licensed security installer.
2. This product may not perform as expected if installed incorrectly.
3. Some features of this product, including but not limited to Back to Base reporting, SMS and Email Reporting and Automatic Time and Date Adjustments require a working telephone line to operate and telephone communication service provider charges are applicable.
4. Australian standard AS 2201 requires regular service by qualified and licensed security persons and regular user testing. Please consult your security alarm company for further details.
5. Incorrect programming of parameters can result in operation contrary to what may be desired.
6. Leave the mains adapter plugged in at all times.
7. Leave the telephone line plugged in at all times under normal conditions.
8. The Product Identification Label for this product which is supplied in the resistor pack, must be affixed to the outside of the enclosure during installation.





9. This equipment shall not be set up to make automatic calls to the Telecom '111' Emergency Service.

Copyright © 2002-2022 Digiflex Pty Ltd

TABLE OF CONTENTS

Copyright Notice 2
Trademarks 2
Notice of Liability 2
Telepermit Note 2
FEATURES 4
OVERVIEW 4
ABOUT THE PANEL 5
Enclosures 5
Enclosure Fixing Method 5
Installing The Tamper Switch 5
Enclosure Module Spaces 5
Installing Panels and Modules 6
Connecting Power To The Panel 8
Connecting The Battery 8
AC Mains Transformer Option 8
Panel LED Indicators 8
WIRING DIAGRAMS 9
EOL Resistor Colours and Values 9
LAN Overview 10
LAN Wiring 10
System Earthing 11
Terminating the LAN 11
PCB Layout 12
Connection Diagram 13
Terminal Descriptions 14
Board Connectors 14
ABOUT THE KEYPAD 15
Status Icons / LED's 16
Keypad Tones 16
Keypad & Readers Setup 17
DIP Switch Address Select 17
Rotary Switch Address Select 17
Programming Overview 18
Entering Programming Mode 18
Exiting Programming Mode 18
Navigating The Menu 18
Command Menu 18
Programming Option Bit Menus 18
Alpha Text 18
List Options 19
Clock Programming 19
GETTING STARTED WITH MYALARM 19
SERVICE MODE 19
DEFAULTING THE SYSTEM 19
DIRECT LINK PROGRAMMING 20
ZONE ARRAY 20
DOOR ARRAY 20
OUTPUT ARRAY 20
BASIC REPORTING REFERENCE 21
MENU REFERENCE TABLE 22
PROGRAM LOCATIONS 25
Access Programming 25
User Default Table 25
Area Programming 27
Input Programming 29
Zone Assignments 30
Zone Default Table 31
Output Programming 33
Output Default Table 33
Output Event Types 34
Output Assignments 35
One Shot Mode 35
Pulsing Mode 35
Door Properties 36
RF Outputs 36
Macros and Scenes 37
Comms Programming 38
Device Programming 43
System Programming 46
Testing The System 50
Installation Details 51
Specifications 52

FIGURES

Figure 1: PCB and Mounting Clip Installation Diagram 5
Figure 2: Tamper Bracket Installation 5
Figure 3: MW720 - Small Enclosure Details 6
Figure 4: PCB Mounting Clip 6
Figure 5: MW720 Configuration Examples 6
Figure 6: MW730 - Large Enclosure Details 7
Figure 7: MW730 Configuration Examples 7
Figure 8: Internal Transformer Connection Diagram 8
Figure 9: N/C No EOL Zone 9
Figure 10: N/C Single EOL Zone 9
Figure 11: N/C Split EOL Zone 9
Figure 12: N/C Zone With Tamper 9
Figure 13: N/O No EOL Zone 9
Figure 14: N/O Single EOL Zone 9
Figure 15: N/O Split EOL Zone 9
Figure 16: N/O Zone With Tamper 9
Figure 17: EOL Resistor Colour Chart 9
Figure 18: LAN Connection Using 2 Pair Security Cable 10
Figure 19: LAN Connection Using Twisted Pair Cable 11
Figure 20: Vision-XIP Board Layout 12
Figure 21: Vision-XIP Connection Diagram 13
Figure 22: Keypad Emergency Alarm Trigger's 15
Figure 23: Keypad DIP Switch Address Settings 17
Figure 24: Rotary Swich Address Settings 17
Figure 25: Sample Option Bit Menu Display 18
Figure 26: Area Text Programming Display 18
Figure 27: List Option Programming Display 19
Figure 28: Clock Programming Display 19
Figure 29: Custom Installer Baner Sample 50

TABLES

Table 1: Expansion Options 5
Table 2: Dialler Indicator LED 8
Table 3: Status Indicator LED 8
Table 4: Terminal Block Descriptions 14
Table 5: Board Connector Descriptions 14
Table 6: Keypad Key Functions 15
Table 7: ICON & LED Indicator Meanings 16
Table 8: Keypad Tones 16
Table 9: DIP Switch Address Settings 17
Table 10: Rotary Switch Address Settings 17
Table 11: Keys Used During Programming 18
Table 12: Text Keypad Character Set 18
Table 13: Shortform Point ID Listing 21
Table 14: Menu Structure And Layout 24
Table 15: User Default Programming Options 25
Table 16: Zone Assignments 30
Table 17: Zone Defaults 31
Table 18: Output Default Table 33
Table 19: Output Event Types 34
Table 20: Address Configuration and Output Assignments 35
Table 21: One-Shot Polarity Example 35

Copyright © 2002-2022 Digflex Pty Ltd

Features

Listed below are the main features of the Vision-XIP Control Panel.

- Individual Box Tamper Circuit Monitoring
- Daylight Savings
- Senior Watch
- GSM/GPRS/Ethernet Reporting Options
- System Maintenance Interval Reminder
- System Weekly Test Reminder
- Area Inactivity Interval
- Up to 16 Access Doors
- Temporary PIN
- Dual Reporting
- Dual Redundant Reporting
- Alarm Report Abort/Cancel Options
- 8 Programmable Holiday Calendars
- 16 Programmable TimeZones
- 8 On-board Zones (Single EOL) / 16 On-Board Zones (Dual EOL)
- Expandable To 144 Zones)
- Fire Alarm Verification
- 990 PIN Users
- 4 Supervised High Power Digital Outputs
- 1 Relay 2 Amp Form (C) Contact (Expandable to 32)
- Supervised Siren Driver
- Partitionable To 8 Areas
- Supervised LAN Keypads (Maximum 16 Keypads)
- Keyswitch Input
- 2000 History Event Memory
- EMI / Lightning Transient Protection
- Fully Menu Text Programmable
- Programmable Via VisionLink Software (Remote/ Direct)
- TimeZone Executed Functions
- 60+ Output Event Types
- Exit Restart
- Expansion Module Supervision
- Remote Arming
- Fingerprint Reader Options

Overview

Zones

The Vision-XIP control panel provides up to 144 separate zones of protection. Zone programming determines the panel's response to open/short and tamper conditions on the zone loop.

Areas

The control panel supports up to 8 separate areas. You can assign all zones to a single area, or you can assign each zone to a combination of different areas.

You can arm and disarm the control panel by area, alternatively, you can arm and disarm several areas at the same time.

Dialler

The control panel has a built-in dialler to send reports to the receiving party (ie. Security company monitoring station, mobile phone etc).

Keypads

You can connect a maximum of 16 fully supervised keypads to the control panel. The available current affects the total number of keypads that you can connect without the need to provide additional power supplies.

History Log

The control panel can store up to 2000 history events from all 8 areas. All events are stored in the log, even if they are programmed not to report via the on-board dialler.

You can view the control panel's history log via keypad, or by connection of a personal computer (direct/remote) using the SolutionLink upload/download software.

Programming

You can program the Vision-XIP either by a keypad or using a personal computer using the VisionLink upload/ download software.

Copyright © 2002-2022 Digflex Pty Ltd

About The Panel

Enclosures

The MW720 - Small Enclosure and MW730 - Large Enclosure have been designed to reduce installation time and improve aesthetics on larger installations where often multiple enclosures need to be located in close proximity to each other.

A number of new features have been incorporated including a new style tamper bracket which can be easily installed before or after the enclosure is mounted to the wall, an anti tamper lid which insures the cabinet tamper triggers when the lid is removed, easier access for flexible and rigid conduits, additional 20mm cable entry knockouts and a new board mounting system using removable spring clips.

The MW720 and MW730 enclosures include numerous holes, allowing the PCB mounting clips to be positioned in the most appropriate location for each installation.

Note ***For ease, it is recomended that the PCB mounting clips are installed from the rear of the enclosure before mounting it to the wall.***




Figure 1: PCB and Mounting Clip Installation Diagram

Enclosure Fixing Method

CM720 - Small Enclosure

Use appropriate fasteners capable of handling a minimum of 6kg to fix the cabinet against a sturdy surface using the mounting holes provided.

CM730 - Large Cabinet

Use appropriate fasteners capable of handling a minimum of 12kg to fix the cabinet against a sturdy surface using the mounting holes provided.

Installing The Tamper Switch

The tamper switch can be located on either the left or right hand side of the cabinet to suit the installation. Before installing the bracket, fit the tamper lead to the switch and then insert it into the bracket.

Once the enclosure has been mounted to the wall, insert the tamper bracket into the rectangular hole in the top flange of the enclosure and then slide the base of the bracket toward the top until the tamper switch locates in the rear of the enclosure.

Depress the tamper a few times with your finger to ensure smooth operation.



Figure 2: Tamper Bracket Installation

Enclosure Module Spaces

The MW720 enclosure has space for 2 large modules or 4 small modules while the optional MW730B enclosure has space for up to 4 large modules or 8 small ones. The enclosures have been designed so that any combination of large and small units can be neatly mounted together on the wall.

Each module is mounted to the enclosure using 4 or more clip in standoffs. The clips can be inserted from the rear of the enclosure before mounting it to the wall, or from the front of the enclosure after it has been mounted. Both methods should be performed using your finger tips to prevent damage to the standoff. (Standoffs and screws are supplied with each module).

All compatible add on modules will mount on these spaces. See below for list if modules which can be added to the control panel.

Module	Space Occupied
Vision-XIP Control Panel	2 Module Spaces
CM704 Zone Expander	1 Module Space
CM705 Universal Expander	2 Module Spaces
CM710 Output Expander	1 Module Space
CM720 LAN Power Supply	1 Module Space
CM760 Real Time Clock	1 Module Space
CM797 LAN Isolator Module	1 Module Space
CM195 RF Receiver Expander	1 Module Space

Table 1: Expansion Options

Use the above table to help determine which size cabinet you will require for the job.

On some export models, one module space will not be available as the mains transformer mounts in this location.

Copyright © 2002-2022 Digflex Pty Ltd

Installing Panels and Modules

Once the enclosure is secured in place, install the panels and modules onto the mounting clip using the supplied 3mm screws. Do not over tighten the screws.

When fitting panels or large modules, you should use 5 mounting clips, one in each corner of the PCB and one in the middle of the PCB underneath the main terminal blocks. When mounting small modules, only 4 clips are required, 1 in each corner.

Both enclosures are supplied with tamper switches, tamper leads, tamper brackets and a quantity of mounting clips and screws. If required, additional mounting clips and screws may be purchased in bags of 50 clips (10 packs x 5pcs). (P/N: MW890)

The supplied mounting clips are designed to use the 3mm machine screws supplied with the enclosure. The use of self tapping screws will damage the clips.




Figure 3: MW720 - Small Enclosure Details





Figure 4: PCB Mounting Clip

The following example shows the MW720B - Small enclosure configured using 4 small modules.



When installing small modules, you should fit 4 mounting clips as shown.

When installing large modules, you should fit 5 mounting clips as shown. Clip 5 provides support under the main terminal block only. No screw is fitted.




Figure 5: MW720 Configuration Examples

Copyright © 2002-2022 Digflex Pty Ltd





Figure 6: MW730 - Large Enclosure Details

The following examples show the MW710 -Large enclosure configured using 6 small modules and 1 large module.

When installing large modules you should fit 5 mounting clips as shown.
Clip 5 provides support under the main terminal block only. No screw is fitted.



When installing small modules, you should fit 4 mounting clips as shown.

Figure 7: MW730 Configuration Examples

Copyright © 2002-2022 Digflex Pty Ltd

Connecting Power To The Panel

For normal operation, the panel requires both AC and DC power sources. The AC source can be provided either by an external adapter or by an internal transformer depending on the model and country of sale.

When connecting using the AC adapter, feed the cable in to the enclosure and terminate the wires on the removable terminal block supplied before connection it to the PCB.

If using a 3 wire adaptor, then the earth wire should also be terminated onto the terminal block. Always check the orientation of the terminal block with the PCB markings before connecting it to the PCB.

Connecting The Battery

The panel is supplied with a set of battey leads to suit the chosen enclosure. Connect the RED battery lead to the battery (+) terminal and the BLACK battery lead to the battery (-) terminal on the PCB.

Once terminated onto the PCB connect the other end of the leads to the battery paying attention to the polarity.

AC Mains Transformer Option

On models with an internal transformer, a permanent connection shall be made to the mains supply. See Figure 8. This must be completed by a suitably qualified electrician according to the applicable wiring standards and regulations.

Next connect the transformer output wires (red) to the removable terminal block supplied and then connect it to the PCB. Always check the orientation of the terminal block with the PCB markings before connecting.

Note ***For permanently connected equipment, a readily accessable disconnect device shall be installed in a location near to the equipment.***




Figure 8: Internal Transformer Connection Diagram

Panel LED Indicators

The control panel PCB has two LED indicators (Dialler and Status LED's) which display the following information.

Condition	Meaning
Off	Offline
On	On Line (Dialling/Answered)
Flashing	Incoming Call

Table 2: Dialler Indicator LED

Condition	Meaning
Off	Error
On	Error
Flash Once Every 2 Seconds	OK
Flash Fast	AC or Battery Trouble

Table 3: Status Indicator LED

Note ***During factory defaulting the Status and Dialler LED indicators will flash alternatively for approximately 15 seconds.***

Copyright © 2002-2022 Digflex Pty Ltd

Wiring Diagrams




Figure 9: N/C No EOL Zone




Figure 10: N/C Single EOL Zone




Figure 11: N/C Split EOL Zone




Figure 12: N/C Zone With Tamper

The above diagrams display zone configurations using Normally-Closed Alarm contacts and Normally-Open Alarm Contacts. When using Normally-Open Alarm Contacts you must select Inverted Seal for each zone in MENU 3-1-8. A shorted loop is a tamper condition for all EOL zone configurations.




Figure 13: N/O No EOL Zone




Figure 14: N/O Single EOL Zone




Figure 15: N/O Split EOL Zone





Figure 16: N/O Zone With Tamper

EOL Resistor Colours and Values

Use either the 4 colour, or solid colour resistors supplied.








Figure 17: EOL Resistor Colour Chart

LAN Overview

The control panel communicates with other system module devices via the built in RS485 LAN or Local Area Network.

For increased security, the system uses anti-substitution technology and a proprietary data encryption algorithm to communicate with all LAN modules.

When using the recommended cable types the LAN can be up to 1500 metres in length, or even greater when LAN isolators are used.

See the CM797 LAN Isolation Module reference guide for more information on how to use LAN isolators to increase the overall LAN length, improve surge immunity protection and prevent earth loops.

Note ***It is recommended that one or more CM797 Isolators be used when connecting the LAN between multiple buildings.***

LAN Wiring

Figure 18 and Figure 19 show the two recommended module connection diagrams.

The method shown in Figure 18, is only recommended for use where the total LAN length is 300 metres or less and the system is not installed in a electrically noisy environment. In this case it is possible to use 7/0.20 or 14/0.20 security cable (non twisted) provided that module voltage levels are maintained within specification.

The method shown in Figure 19, offers the greatest immunity to noise interference and voltage surges. This connection method is recommended where the total LAN length is greater than 300 metres. When using twisted pair cable the LAN length can be up to 1500 metres, and this can be extended even further when using LAN isolators.

The LAN can be wired using the daisy chain method as shown, where each module is wired back to the panel on the same cable run or using a star configuration, where individual modules are wired back to the panel on individual wires.

Un-shielded cable can be used successfully in many situations however for the highest reliability and performance in areas prone to frequent electrical storms or high levels of electrical interference, shielded twisted pair cable should be used.

LAN+ and LAN- should not be used to power detectors or other external devices. These devices should be powered from the +12V terminals on the panel or via an external power supply.

When wiring modules with built in power supplies like the control panel and the CM720 Power Supply, do NOT connect the EARTH wire from any 3 wire plug pack to the module's EARTH input terminal, if you have installed a separate communication earth wire.




Figure 18: LAN Connection Using 2 Pair Security Cable

The LAN A and LAN B wires are not interchangeable. Make sure that the LAN A wires from all modules connect to LAN A on the panel and LAN B wires from all modules connect to LAN B on the panel.

Do not connect the positives of two power supply sources together. When wiring the LAN to modules that are self powered, or powered from an external source you should terminate the LAN+ into the terminal marked LOOP. This terminal is simply a termination point and is not internally connected.

Copyright © 2002-2022 Digflex Pty Ltd




Figure 19: LAN Connection Using Twisted Pair Cable

The LAN- terminals from all modules must be connected together for correct operation.

System Earthing

When running a CET communications Earth as per Figure 19, the communication earth should be connected to the earth terminal on each module and then connected back through the CET to the main building earth conductor.

Do NOT connect the plug pack transformers earth wire to any modules earth terminal.

Note

If a separate Communications Earth wire is installed, do NOT connect the EARTH wire from any 3 wire plug pack to any modules EARTH input terminal.

If a separate communications earth is NOT being used, then you should connect the earth wire from the 3 wire plug pack to the panels earth terminal as shown in Figure 19.

When using shielded cable, the shield of each length of cable should only be connected to a protective earth at one end. Do no allow the shield to make contact with negative 0 volts, ground or any other wiring within the system.

All earth wiring should be carried out in accordance with the local wiring regulations in your area.

Terminating the LAN

For reliable operation, the system LAN must be terminated correctly. The control panel and all LAN modules include a LAN TERM pin header and shunt which is used to connect the termination resistor on the module.

When the shunt is installed between the Y pin and the centre pin, the terminator is fitted and when the shunt is between the N pin and the centre pin the terminator is not fitted.

Where all modules are connected to the panel on a single cable run, (Daisy Chained) the terminators should be installed on the first and last modules on the LAN.

If the modules are connected to the panel via multiple cables all running back to the control panel (Star Configuration) then the terminators should be installed on the modules at the end of the two longest cable runs.

There are no LAN terminators on keypads. If a keypad is one of the two furthest devices from the control panel then a 470 ohm 1/2watt resistor can be fitted at the keypad between the LAN A and LAN B terminals.

Note

The LAN must be terminated correctly for correct operation.

Copyright © 2002-2022 Digflex Pty Ltd

PCB Layout




Figure 20: Vision-XIP Board Layout

Copyright © 2002-2022 Digflex Pty Ltd

Connection Diagram




Figure 21: Vision-XIP Connection Diagram

Terminal Descriptions

Nº	Name	Description
1	Earth	Earth wire from this terminal is connected to the Mains earth.
2 3	~ (AC) ~ (AC)	Connection of the AC plug pack transformer
4 5	BAT (-) BAT (+)	Negative and positive connections to the stand-by battery. 12 VDC / 7AH
6 7 8 9 10 11	+12 V +12 V +12 V GND GND GND	These terminals are used to power detectors and LAN devices up to 750 mA.
12 13	LAN + LAN -	These terminals are used to power LAN devices up to 750 mA.
14	LAN A	Connect the LAN A data terminal of any LAN device (eg. Keypads, expansion boards) to this terminal. The control panel supports up to 300 m of 24/0.20 (18 AWG) wire on these terminals.
15	LAN B	Connect the LAN B data terminal of any LAN device (eg. Keypads, expansion boards) to this terminal. The control panel supports up to 300 m of 24/0.20 (18 AWG) wire on these terminals.
16	COMM+	Alarm power capable of providing a maximum of 2.5 Amp (+). This terminal is PTC Fuse protected.
17 18 19 20	OUT 1 OUT 2 OUT 3 OUT 4	Programmable output, capable of providing a maximum of 500 mA (-). This terminal is PTC Fuse protected.
21 22 23	N/C COM N/O	2 A @ 24 VDC Relay Output - Form C contact
24	INPUT	Programmable Input for RF Receivers, Keyswitch and other devices.
25	ZN 1	Zone 1 and 9 sensor loop input (+).
26	GND	Common (-) for Zone 1 and 2 sensor loop.
27	ZN 2	Zone 2 and 10 sensor loop input (+).
28	ZN 3	Zone 3 and 11 sensor loop input (+).
29	GND	Common (-) for Zone 3 and 4 sensor loop.
30	ZN 4	Zone 4 and 12 sensor loop input (+).
31	ZN 5	Zone 5 and 13 sensor loop input (+).
32	GND	Common (-) for Zone 5 and 6 sensor loop.
33	ZN 6	Zone 6 and 14 sensor loop input (+).
34	ZN 7	Zone 7 and 15 sensor loop input (+).
35	GND	Common (-) for Zone 7 and 8 sensor loop.
36	ZN 8	Zone 8 and 16 sensor loop input (+).

Table 4: Terminal Block Descriptions

Note

The maximum combined continuous current draw from the +12V, LAN + and COMM+ terminals must not exceed 1 Amp

Board Connectors

Connector	Description
Service	This socket allow you to connect a service keypad to the panel during installation.
Tamper	This socket is used to connect the panel enclosure tamper switch.
Default	This push button is used to reset the control panel back to factory default.
Serial	This is used to connect serial devices to the control system like the direct link programming module.
Relay	The relay select PIN's allow you to easily program the relay common contact to switch either +12v or GND by fitting a plug on link.
Expansion Port	This port is used to connect additional modules to the control panel (eg. TCP/IP Interface Module etc)

Table 5: Board Connector Descriptions

Copyright © 2002-2022 Digflex Pty Ltd

About The Keypad

The keypad has 20 keys that allow you to input instructions and navigate the programming menu's as required. Some keys have a secondary function which is activated by pressing and holding them down for two seconds. Each key is described below.

Key	Description
0 to 9	The numeric keys allow you to enter your user PIN when required.
MENU	Use the [MENU] and the numeric keys to enter commands. The [MENU] key is also used to go back one level when navigating through menus or to exit a programming location without saving changes.
ALL ON ON	The [ON] key allows you to turn an area or output on. To turn all areas on at the same time when the system has been partitioned, press and hold the [ON] key for two seconds.
BYPASS PART	The [PART] key allows you to turn an area Part On. This key can also be used to bypass a zone or multiple zones when you press and hold for two seconds after you enter your PIN.
ALL OFF OFF	The [OFF] key allows you to turn an area or output off. To turn all areas off at the same time when the system had been partitioned, press and hold the [OFF] key for two seconds after you enter your PIN.
OK	The [OK] key allows you to save any changes and exit the command.
TEST MAIL	The [MAIL] key allows you to read stored mail. This key can also be used to initiate a dialler test when you press and hold for two seconds.
←	The [←] key allows you to move the cursor left when programming text or telephone numbers.
→	The [→] key allows you to move the cursor right when programming text or telephone numbers.
↑	The [↑] key allows you to navigate through menus or to toggle characters when programming telephone numbers.
↓	The [↓] key allows you to navigate through menus or to toggle characters when programming telephone numbers. Pressing The [↓] key will display current trouble conditions when the area that the keypad is displaying is disarmed.
→ + ↑ for 2 sec	Press and hold the [→] and [↑] keys together for 2 seconds will initiate a panic emergency alarm to be triggered. If programmed, the sirens will sound and the monitoring station will be notified.
← + → for 2 sec	Press and hold the [←] and [→] keys together for 2 seconds will initiate a fire emergency alarm to be triggered. If programmed, the sirens will sound and the monitoring station will be notified.
↑ + ↓ for 2 sec	Press and hold the [↑] and [↓] keys together for 2 seconds will initate a medical emergency alarm to be triggered. If programmed, the sirens will sound and the monitoring station will be notified.

Table 6: Keypad Key Functions




Figure 22: Keypad Emergency Alarm Trigger's

Copyright © 2002-2022 Digflex Pty Ltd

Status Icons / LED's

The following table lists the function of each of the ICON symbols and LED indicators on the keypad display.

Icon	Status	Meaning
1 2 3 4 5 6 7 8	The keypad can be programmed to display area icons (1 to 8) that allow users to easily identify which areas have been turned on or off without the need to toggle between areas (See MENU 6-1-4).	
	On	The area is turned All On or Part On
	Off	The area is turned Off
	Flashing Fast	The area has an alarm
	On	System power is normal
	Flashing	System power is missing
	Flashing	A fire alarm is active
	Off	No fire alarm
	On	Fire alarm in memory (Turn the area All On and Off to Clear).
	On	The existing service or trouble condition has been acknowledged.
	Off	No service or trouble conditions exist
	Flashing	A service or trouble condition is present that has not been acknowledged.
	On	The area is turned Part On.
	Off	The area is not turned Part On.
	On	The area is turned off.
	Off	The area is turned All On or Part On
	On	The area is turned All On or Part On
	Off	The area is turned Off
	On	All messages have been read.
	Off	Message queue is empty
	Flash	An unread message is in the queue.
	On	Area is ready to turn on (All On / Part On)
	Off	Not ready, Zone Open
Red LED	**On**	All On
	Flashing	Alarm
Green LED	**On**	Area is off.
	Flashing	Area not ready to turn on
Red & Green LED	**Flashing**	Installer programming mode is active.
Wi-Fi Connected	The WiFi enabled keypad or module has successfully connected to your local WiFi network.	
Wi-Fi Not Connected	The WiFi enabled keypad or module is not connected to your local WiFi network.	

Table 7: ICON & LED Indicator Meanings

Keypad Tones

All keypads emit several distinct tones and display text to alert you to system events. The volume of the keypad tones can be adjusted in MENU 6-1-0.

Type	Meaning
Fire Alarm Tone	When a fire zone sounds an alarm, the keypad will sound 3 seconds on and 2 seconds off (repeat).
Burglary Alarm Tone	When a burglary zone activates while your system is turned on, your keypad emits a continuous siren tone. It sounds for the time set by your security company.
Trouble Tone	When a system component is not functioning properly, your keypad sounds 4 fast short beeps followed by a 5 second pause (repeat).
Key Press Tone	Pressing any key on the keypad sounds one short beep, indicating that the key press is accepted.
Entry Delay Tone	When you enter the premises through a zone programmed for entry delay, the keypad sound a Hi/Low tone to remind you to turn off the area. If the area is not turned off before the entry delay expires, an alarm condition will sound and a report may be sent to your alarm company.
Exit Delay Tone	After you turn an area All On, the keypad will sound 1 short beep every second. During the last 10 seconds fast short beeps will be heard. If you don't exit before the delay time expires and an exit delay door is faulted, an alarm occurs.
Error Tone	If you enter an incorrect value when programming, the keypad will sound a 2 second tone.
Menu Mode	The keypad will sound a Lo/Hi tone to indicate you have entered MENU Mode and a Hi/Lo tone to indicate you have exited MENU mode.
Chime Tone	The keypad sounds fast short beeps to alert you when a zone programmed for chime is faulted or unsealled.

Table 8: Keypad Tones

Copyright © 2002-2022 Digflex Pty Ltd

Keypad & Readers Setup

The control panel can have a maximum of 16 keypads and/or readers connected via the LAN terminals. Each keypad or reader must be set to a unique address before they will operate.

Each keypad or reader needs to be assigned to a home area via MENU 6-1-3. This sets the area the keypad or reader will display and control by default. Keypads and readers can be locked to a home area or allowed to roam or move between areas. At factory default, the home area is factory default to operate Area 1.

Set each keypad or reader address using "Table 9: DIP Switch Address Settings" on page 17 and "Table 10: Rotary Switch Address Settings" on page 17 as a guide.

Note ***Only 1 keypad can be assigned to each address. All keypads are supplied from the factory set to address 1. (OFF-OFF-OFF-OFF).***

DIP Switch Address Select




Figure 23: Keypad DIP Switch Address Settings

DIP Switch Address Settings				
Keypad/Reader N°	**S1**	**S2**	**S3**	**S4**
1	Off	Off	Off	Off
2	On	Off	Off	Off
3	Off	On	Off	Off
4	On	On	Off	Off
5	Off	Off	On	Off
6	On	Off	On	Off
7	Off	On	On	Off
8	On	On	On	Off
9	Off	Off	Off	On
10	On	Off	Off	On
11	Off	On	Off	On
12	On	On	Off	On
13	Off	Off	On	On
14	On	Off	On	On
15	Off	On	On	On
16	On	On	On	On

Table 9: DIP Switch Address Settings

Rotary Switch Address Select

Keypads and readers fitted to the system must be assigned a unique address on the LAN. Some keypads and readers include a rotary address switch for quick selection.

The following table shows how to set the address setting for each keypad and reader, as well as the number of devices the panel can support.

Rotary Switch Address Settings	
Address Number	**Keypad/Reader N°**
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16

Table 10: Rotary Switch Address Settings



Figure 24: Rotary Swich Address Settings

Copyright © 2002-2022 Digflex Pty Ltd

Programming Overview

The control panel incorporates a menu text driven interface. This interface is very similar to that found on many mobile phones. Once programming mode is entered you will see a number of menu options in the display and these may vary depending in the user authority level.

Entering Programming Mode

To enter installer program mode enter, PIN + [MENU].

The default Installer PIN is 1234.

The Red and Green LED indicators on the keypad will flash to confirm Installer programming mode is active.

Exiting Programming Mode

Press and hold down [MENU] key for 2 seconds.

Navigating The Menu

Using the up and down arrow keys to navigate, locate the desired menu item using the highlight bar and then press the [OK] key to select.

A new list of menu items will appear. Repeat the above until the desired menu item is located.

To navigate backwards through the menu items press the [MENU] key at any time. Alternatively if you know the direct menu item number press [MENU] + Item Number.

Key	Description
←	Scrolls Cursor Left
→	Scrolls Cursor Right
↑	Scrolls Cursor Up
↓	Scrolls Cursor Down
OK	Enter Menu Options or Saves Changes
MENU	Go Back One Level, Hold Down to Exit Programming Mode
0 to 9	Enter Data Value
ON	Turn On Bit Option
OFF	Turn Off Bit Option, Clear to End of Line

Table 11: Keys Used During Programming

Command Menu

When you first enter programming mode a special menu called the Command Menu will appear at the top of the menu tree. The Command Menu provides a list of the most common system funtions like "Turn Chime Mode On", "Move To An Area" or "Turn An Area On". Use the up and down arrow keys to navigate and press [OK] to select the command.

Programming Option Bit Menus

Use the up and down arrow keys to scroll through the 8 different options. To select an option, press the [ON] key – a tick [✓] will be displayed. To deselect an option, press the [OFF] key.




Figure 25: Sample Option Bit Menu Display

To save programming changes, press [OK], else press [MENU] to exit without saving.

Alpha Text

Text descriptions are available for Area Name, Zone Name, User Name, TimeZone Name, Holiday Name Prox Reader Name and Output Name. Each name can have a maximum of 20 characters.




Figure 26: Area Text Programming Display

When programming text, each numeric key represents a different group of characters.

Pressing the same numeric key repeatedly will step you through the available characters assigned to the key. The text key layout is the same as most phones. Refer to the table below for detailed character information.

Key	Characters Assigned To Each Numeric Key								
1	.	,	?	!	-	&	`	1	
2	A	B	C	a	b	c	2		
3	D	E	F	d	e	f	3		
4	G	H	I	g	h	i	4		
5	J	K	L	j	k	l	5		
6	M	N	O	m	n	o	6		
7	P	Q	R	S	p	q	r	s	7
8	T	U	V	t	u	v	8		
9	W	X	Y	Z	w	x	y	z	9
0	SPACE	0							
↑	Scroll Up through entire character list								
↓	Scroll Down through entire character list								
←	Move to left one character position								
→	Move to right one character position								
OFF	Clear from cursor postiion to end of line								

Table 12: Text Keypad Character Set

Once the desired character is displayed press the right arrow key to move to the next character position. To save programming changes, press [OK], else press [MENU] to exit without saving.

Copyright © 2002-2022 Digflex Pty Ltd

Note ***The following additional special characters are available by scrolling using the up and down arrow keys. + - @ # $ " & % * : ( ) / < > =***

List Options

Use the [↑] and [↓] keys to step through the available options. Press [OK] to save or [MENU] to exit without saving.

Note ***You can also enter the option number directly followed by [OK].***




Figure 27: List Option Programming Display

Clock Programming

Use the left and right arrow keys to move to the field then use the up and down arrow keys to change. Press [OK] to save or [MENU] to exit without saving.

Note ***Scroll through hours to change from am to pm.***




Figure 28: Clock Programming Display

Getting Started With MyAlarm

To get the panel registered ono the MyAlarm platform follow these steps.

1. Panel from factory setting.
2. Establish an IP connection using ethernet module, WiFi keypad or cellular radio
3. Register an installer account at https://myalarm.com.au if you don't already have one.
4. Take note of the 11 digit installer numberr (top right of your screen or in your MyAlarm confirmation email)
5. Enter installer panel programming mode on the keypad
6. Select MENU 5-0-9
7. Enter our 11 digit installer number and press [OK]
8. Panel will take up to 1 minute to register successfully to the MyAlarm servers
9. Login to https://www.myalarm.com.au and on the home page you will see your newly registered panel
10. Select the serial number of your panel and fill out the site information
11. Select the preferred MyAlarm plan and confirm payment

Service Mode

Service mode when activated disables dialler reporting, prevents all alarms and prevents all users from arming the system.

To Turn Service Mode ON

1. Enter programming mode.
   [1][2][3][4] + [MENU]
2. Turn service mode on.
   MENU 7-0-8
3. Follow display prompts.
4. Hold down [MENU] to exit.

Note ***Keypads will display the word Service when service mode is active.***

To Turn Service Mode OFF

1. Enter programming mode.
   [1][2][3][4] + [MENU]
2. Turn service mode off.
   MENU 7-0-8
3. Follow display prompts.
4. Hold down [MENU] to exit.

Note ***Keypads will display the word Service when service mode is active.***

Defaulting The System

Defaulting the system will reset all programming options back to the factory default setting. All programming information will be erased.

To Hardware Default

1. Remove all power to the system - AC and battery.
2. Press and hold the default push button, then apply power to the control panel.
3. Release the default button, The panel will reset and revert to normal operation when default is complete.

To Software Default

1. Enter programming mode.
   [1][2][3][4] + [MENU]
2. Select factory default option.
   MENU 7-0-4
3. The panel will reset and revert to normal operation when the default is complete.

Copyright © 2002-2022 Digflex Pty Ltd

Note

You can disable factory defaulting using MENU 7-7-4. If factory defaulting has been disabled you must know the installer code to perform a factory default otherwise the system will need to be returned to your supplier for defaulting or you can purchase a CM255 Default Unlock Key which will unlock the panel in the field. Charges apply for defaulting if retuned to the distributor.

Direct Link Programming

The panel can be programmed via the VisionLink Upload/Download software in either Direct Link or Remote Link modes. For Direct Link you will need a CM900 Direct Link module which connected the panels serial port to the PC.

Once the cable is connected you will need to hold down the default switch on the panel for 5 seconds to initiate the programming session. See Figure 20: for the default switch location. It is also possible to initiate the programming session via MENU 5-0-5 - Start Direct Link.


Zone Array

The feature allows you to view the condition of all zones on the panel in banks of 16 zones at a time. From the installer programing mode press MENU 3-0-1 to access the zone array.

Use the [↑] and [↓] arrow keys to scroll up and down the zone banks and press [OK] or [MENU] when finished.

The following information can be displayed depending on the current zone status.

N= NORMAL
S = SHORTED
A= ALARM
T= TAMPER
- = DISABLED



In the above example screen,

N = Zone 01 and 06 are Normal (Sealed)
S = Zone 02 is Shorted
A = Zone 03,05,07 are in Alarm (Unsealed)
T = Zone 08 is in Tamper Alarm (Unsealed)
- = Zone 04, 09-16 are Disabled (Unused)


Door Array

This feature allows you to view door status in groups of 16. From the installer programing mode press MENU 4-0-4 to access the output array.

Press [OK] or [MENU] when finished.

The following information can be displayed depending on the current zone status.

L = Door Locked
U = Door Unlocked
O = Override
- = Disabled or Not Available



In the above example screen,
L = Doors 01 to 05 are Locked
O = Door 13 has a Override condition
U = Doors 09 to 12 area Unlocked
- = Doors 06 to 08 and Doors 14 to 16 are Disabled or Not Available

Output Array


This feature allows you to view output status in groups of 16. From the installer programing mode press MENU 4-0-2 to access the output array.

Use the up and down arrow keys to scroll up and down the output banks and press [OK] or [MENU] when finished.

The following information can be displayed depending on the current zone status.

N = NORMAL - Off Condition
T = TRIGGERED - On Condition
F = FAULT - Overload Condition
- = DISABLED

1. Enter [MENU] + [4] + [0] + [2] and use the up and down arrows to select the output group to view.
2. Use the [↑] and [↓] down arrows at any time to move to a new group. The keypad will display the following output array information for outputs 1 to 16.



In the above example screen,
N = Outputs 01 to 05 are Normal (Off)
F = Output 10 has a Fault (Overload)
T = Output 09 is Triggered (On)
- = Outputs 05 to 08 and Outputs 11 to 16 are Disabled or Not Available

Copyright © 2002-2022 Digflex Pty Ltd

Basic Reporting Reference

A complete reporting template is available on the VisionLink CD or from your nearest Digiflex security products outlet. Your base station will need to create a specific reporting template for this and other Digiflex Vision panels.

Point ID Table	Module Description
Ur999	Installer
Ur998	Remote User
Ur997	TimeZone
Ur996	Guard Tour
Ur001 - 995	Users
Ur000	Quick Arm
Zn001 - 200	Zones General
Zn201 - 264	Doors 1 - 64 or Zones 201 - 264
Zn301 - 428	User Keyfob 1-128
Zn429 - 556	User Keyfob 129 - 256
Zn701 - 708	Door Controller 1 - 8
Zn711 - 718	Door Controller 9 - 16
Zn761 - 768	Lift Controller 1 - 8
Zn771 - 778	Lift Controller 9 - 16
Zn781 - 788	Input Expander 1 - 8
Zn791 - 798	Input Expander 9 - 16
Zn801 - 808	Universal Expander 1 - 8
Zn811 - 818	Universal Expander 9 - 16
Zn821 - 828	RF Receiver 1 - 8
Zn831 - 838	LAN Power Supply 1 - 8
Zn841 - 848	Serial Expander 1 - 8
Zn851 - 858	Output Expander 1 - 8
Zn860	GSM Module
Zn861	GSM Input 1
Zn862	GSM Input 2
Zn863	GSM Input 3
Zn864	GSM Input 4
Zn870	Ethernet Module
Zn871	Real Time Clock Module
Zn872	Voice Module
Zn873	Service Keypad
Zn881 - 888	Consoles 1 - 8
Zn891 - 898	Control Panel 1 - 8
Zn911 - 918	LAN Isolator 1 - 8
Zn921 - 928	LAN Isolator 9 - 16
Zn901 - 908	Destination Route 1 - 8
Zn971 - 978	Consoles 9 - 16
Zn901 - 908	Destination Route 1 - 8
Zn911 - 918	LAN Isolator 1 - 8
Zn921 - 928	LAN Isolator 9 - 16
Zn931 - 938	LAN Power Supply 9 - 16
Zn951 - 958	Output Expander 9 - 16
Zn971 - 978	Consoles 9 - 16

Table 13: Shortform Point ID Listing

Copyright © 2002-2022 Digflex Pty Ltd

Menu Reference Table

The control panel includes a simple text menu system which makes all levels of programming extremely easy. Once a valid PIN has been entered followed by the MENU key the system will automatically determine which menus and option the user has access to and only those items will be displayed.

There are four basic grouping levels used;

1. A = All (No PIN Required)
2. U = User PIN Has Access
3. M = Master PIN Has Access
4. I = Installer PIN Has Access

The following table lists all programming menus and the authority level required to access them.

	0	Commands
UMI	2-0-1	Turn Area On/Off
UMI	2-0-2	Turn All Areas On
UMI	2-0-3	Turn All Areas Off
UMI	2-0-4	Move To Area
AUMI	2-0-5	Chime On/Off
UMI	1-1-0	Change Own PIN
AUMI	3-0-0	Zone Status
AUMI	4-0-0	Output Status
UMI	4-0-1	Turn Output On/Off
MI	7-1-0	Set Date And Time
UMI	3-0-5	Smoke Sensor Reset
UMI	3-9-0	Walk Test All Zones
MI	4-9-0	External Siren Test
MI	4-9-1	Internal Siren Test
MI	4-9-2	Strobe Test
UMI	7-9-1	Battery Test
UMI	5-9-0	Send Test Report
I	7-0-8	Service Mode
UMI		About

	1	Access
	1-0	**Commands**
MI	1-0-0	Erase User
	1-1	**PIN Codes**
UMI	1-1-0	Change Own PIN
MI	1-1-1	Change Other PIN
MI	1-1-2	Add PIN
MI	1-1-3	Delete PIN
I	1-1-4	View PIN
	1-2	**Token**
MI	1-2-0	Add Token
MI	1-2-1	Delete Token
MI	1-2-2	Token Status
MI	1-2-3	Edit Token
	1-3	**RF Keyfob**
MI	1-3-0	Add Keyfob
MI	1-3-1	Delete Keyfob
I	1-3-2	Test Keyfob
	1-4	**User Properties**
MI	1-4-0	User Name
MI	1-4-1	Area Assignment
MI	1-4-2	User Options
MI	1-4-4	TimeZone Access
MI	1-4-5	Door Assignment
MI	1-4-6	User Expire Date
	1-5	**Global Properties**
I	1-5-0	PIN Length
I	1-5-1	PIN Retry Count
I	1-5-2	Installer PIN
	1-6	**Reporting**
I	1-6-0	Access Route
I	1-6-1	Access Options
	1-8	**Fingerprint**
MI	1-8-0	Add Fingerprint
MI	1-8-1	Delete Fingerprint
MI	1-8-2	Fingerprint Status

	2	Areas
	2-0	**Commands**
AUMI	2-0-0	Area Status
UMI	2-0-1	Turn Area On/Off
UMI	2-0-2	Turn All Areas On
UMI	2-0-3	Turn All Areas Off
UMI	2-0-4	Move To Area
AUMI	2-0-5	Chime On/Off
MI	2-0-6	Chime Mode
	2-1	**Area Properties**
MI	2-1-0	Area Name
I	2-1-1	General Options
I	2-1-2	Input Options
I	2-1-3	Output Options
I	2-1-4	Reporting Options
I	2-1-5	Strobe Trigger
MI	2-1-6	Part Mode 1 Name
MI	2-1-7	Part Mode 2 Name
MI	2-1-8	Auto Arming
	2-2	**Reporting**
I	2-2-0	Account Dest 1
I	2-2-1	Account Dest 2
I	2-2-2	Open Close Route
	2-8	**Timers**
MI	2-8-0	Exit Time
MI	2-8-1	Entry Time 1
MI	2-8-2	Entry Time 2
MI	2-8-3	Part Entry Time
I	2-8-4	Auto Arm Pre Alert
I	2-8-6	Senior Watch Time
	2-9	**Area Testing**
I	2-9-0	Area Watch
I	2-9-1	User Test Interval
I	2-9-2	Service Interval
I	2-9-3	Test Options

Copyright © 2002-2022 Digflex Pty Ltd

	3	Inputs
	3-0	**Commands**
AUMI	3-0-0	Zone Status
IM	3-0-1	Zone Array
UMI	3-0-2	Bypass Zones
MI	3-0-3	Set Chime Zones
MI	3-0-4	Set Part 2 Zones
UMI	3-0-5	Smoke Sensor Reset
	3-1	**Zone Properties**
MI	3-1-0	Zone Name
I	3-1-1	Zone Type
I	3-1-2	Area Assignment
I	3-1-3	Pulse Count
I	3-1-4	Pulse Count Time
I	3-1-5	Door Assignment
I	3-1-6	Report Route
I	3-1-7	Report Options
I	3-1-8	Zone Options
	3-3	**RF Zone**
I	3-3-0	Add RF Device
I	3-3-1	Delete RF Device
I	3-3-2	Test RF Device
I	3-3-3	Zone Properties
I	3-3-3-0	Gross Attack
I	3-3-3-1	Minor Attack
I	3-3-3-3	Zone Options
	3-4	**Global Input Options**
I	3-4-0	EOL Value
I	3-4-1	Keyswitch Options
I	3-4-2	Input Options
	3-5	**PGM Input**
I	3-5-0	Input Type
	3-6	**Tamper Inputs**
I	3-6-0	Tamper Options
	3-9	**Input Testing**
UMI	3-9-0	Walk Test All Zones
UMI	3-9-1	Walk Test A Zone
I	3-9-2	Sensor Watch Time

	4	Outputs
	4-0	**Commands**
AUMI	4-0-0	Output Status
UMI	4-0-1	Turn Output On/Off
MI	4-0-2	Output Array
MI	4-0-3	Door Status
MI	4-0-4	Door Array
MI	4-0-5	Door Control
MI	4-0-6	Macro Array
	4-1	**Properties**
MI	4-1-0	Output Name
I	4-1-1	Event Type
I	4-1-2	Event Assignment
I	4-1-3	Output Polarity
I	4-1-4	Time Parameter
I	4-1-5	Output Options
	4-2	**Door Properties**
MI	4-2-0	Door Name
I	4-2-2	Unlock TimeZone
I	4-2-3	Door Options
	4-3	**RF Output**
I	4-3-0	Add RF Output
I	4-3-1	Delete RF Output
I	4-3-2	Test RF Output
	4-8	**Macros**
MI	4-8-0	Name
MI	4-8-1	Macro Rule
MI	4-8-2	Scene
	4-9	**Output Testing**
MI	4-9-0	External Siren Test
MI	4-9-1	Internal Siren Test
MI	4-9-2	Strobe Test
MI	4-9-3	Fire Siren Test

	5	Comms
	5-0	**Commands**
MI	5-0-5	Start Direct Link
MI	5-0-8	Register Customer
I	5-0-9	Register Installer
	5-2	**Properties**
I	5-2-1	Report Options
I	5-2-3	Country
	5-3	**Remote Access**
I	5-3-1	RAS Security PIN
I	5-3-2	Log Threshold
I	5-3-8	User RAS PIN
	5-4	**Reporting**
I	5-4-0	TX Format Dest 1
I	5-4-1	TX Format Dest 2
I	5-4-2	Test Route
I	5-4-3	System Route
I	5-4-4	Emergency Route
I	5-4-5	Swinger Dialler
I	5-4-6	Burg Report Delay
I	5-4-7	Fire Report Delay
	5-5	**MyAlarm**
I	5-5-0	IP Address
I	5-5-1	IP Port
I	5-5-2	MyAlarm Options
	5-6	**IP Reporting**
I	5-6-0	Receiver IP
I	5-6-1	Receiver Port
I	5-6-2	Poll Rate
I	5-6-3	ACK Wait Time
I	5-6-4	IP Format
I	5-6-5	Retry Count
I	5-6-6	Encryption Key
I	5-6-7	Conettix NNC
I	5-6-8	SIA IP Prefix
I	5-6-9	User Name/Password
I	5-6-1-0	Reporting Options
	5-7	**IP Remote Access**
MI	5-7-0	IP Address
MI	5-7-1	IP Port
I	5-7-2	IP RAS Options
I	5-7-3	RAS Lockout Time
I	5-7-5	IPRS Address
I	5-7-6	IPRS Port
	5-9	**Comms Test**
UMI	5-9-0	Send Test Report
I	5-9-1	Test Report Time
I	5-9-2	Test Report Period
I	5-9-3	Test Report Options
I	5-9-4	Test Route

Copyright © 2002-2022 Digflex Pty Ltd

	6	**Devices**
	6-0	**Commands**
UMI	6-0-0	Device Status
I	6-0-1	LAN Secure
I	6-0-2	LAN Scan
I	6-0-3	LAN Watch
MI	6-0-7	Keypad Volume
MI	6-0-8	Keypad Contrast
MI	6-0-9	Keypad Backlight
	6-1	**Keypads & Readers**
MI	6-1-0	Name
I	6-1-2	Area Options
I	6-1-3	Home Area
I	6-1-4	General Options
I	6-1-5	Indicator Options
I	6-1-6	Emergency Keys
I	6-1-7	Door Assignment
I	6-1-8	Lockout Time
MI	6-1-9	WiFi Settings
	6-2	**RF Devices**
I	6-2-0	Receiver Options
I	6-2-1	Supervision Time
I	6-2-2	RF Device Options
I	6-2-3	Add RF Keypad
I	6-2-4	Delete RF Keypad
I	6-2-5	View RF Device ID
I	6-2-6	Smart Keyfob
I	6-2-9	RF Site Key
	6-5	**GSM/GPRS**
MI	6-5-0	GSM/GPRS Status
I	6-5-1	GSM/GPRS Options
I	6-5-7	APN Server Name
I	6-5-8	APN Username
I	6-5-9	APN Password
	6-6	**Ethernet Module**
I	6-6-0	IP Address
I	6-6-1	Subnet Mask
I	6-6-2	Default Gateway
I	6-6-3	MAC Address
I	6-6-9	Ethernet Options

	7	**System**
	7-0	**Commands**
UMI	7-0-0	Panel Status
UMI	7-0-1	System Trouble
UMI	7-0-2	History Log
I	7-0-4	Factory Default
I	7-0-5	Template Default
MI	7-0-6	TimeZone Array
I	7-0-8	Service Mode
	7-1	**Clock**
MI	7-1-0	Set Date And Time
I	7-1-1	Summertime On
I	7-1-2	Summertime Off
I	7-1-3	Locale
I	7-1-4	Clock Options
	7-3	**Power**
I	7-3-0	AC Options
I	7-3-1	Battery Options
I	7-3-2	Fuse Options
	7-4	**Siren**
I	7-4-0	Tone
I	7-4-1	Speed
MI	7-4-2	Volume
I	7-4-3	Siren Swinger
	7-5	**TimeZones**
MI	7-5-0	Name
MI	7-5-1	Time
MI	7-5-2	Day
MI	7-5-3	TimeZone Options
	7-6	**Holidays**
MI	7-6-0	Holiday Name
MI	7-6-1	Start Stop Dates
	7-7	**System Options**
I	7-7-0	General Options
I	7-7-1	Area Options
I	7-7-2	Keypad Idle Screen
MI	7-7-3	Keypad Hi/Lo Temp
I	7-7-4	Installer Options
I	7-7-5	Language
MI	7-7-7	Site Name
I	7-7-8	Custom Text Line 1
I	7-7-9	Custom Text Line 2
	7-9	**System Testing**
UMI	7-9-0	Walk Test All Zones
UMI	7-9-1	Battery Test

Table 14: Menu Structure And Layout

Copyright © 2002-2022 Digflex Pty Ltd

Program Locations

The following section lists all of the programming locations available in the Vision-XIP. The default values for each parameter are shown in grey.

In order to keep the size of this guide down to a minimum we have shown only one example for some parameters and then listed the default values for the other similar parameters. For example the user default table below shows the default values for users 1 to 990. Similar tables are used to show zone defaults etc.

Access Programming

Access > Commands >

Erase User	**MENU 1-0-0**

Access > PIN Codes >

Change Own PIN	**MENU 1-1-0**
Change Other PIN	**MENU 1-1-1**
Add PIN	**MENU 1-1-2**
Delete PIN	**MENU 1-1-3**
View PIN	**MENU 1-1-4**

Access > Token >

Add Token	**MENU 1-2-0**
Delete Token	**MENU 1-2-1**
Token Status	**MENU 1-2-2**
Edit Token	**MENU 1-2-3**

User Default Table

Parameter	User 1	User 2 - 990
User PIN	2580	
Name	User 1 Name	User 2 - 990
Area Assignment	1	1
User Options		
Master User	Y	
Arm Only		
Can Bypass	Y	Y
Auto Bypass	Y	Y
Always Report Op/Cl	Y	Y
Log Credential		
TimeZone	01	01
Door Assignment		

Table 15: User Default Programming Options

Access > RF Keyfob >

Add Keyfob	**MENU 1-3-0**
Delete Keyfob	**MENU 1-3-1**
Test Keyfob	**MENU 1-3-2**

Access > User Properties >

User Name	**MENU 1-4-0**

U	s	e	r		1		N	a	m	e									

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Access > User Properties >

Area Assignment	**MENU 1-4-1**

1	Security System	Y
2	Area 2 Name	N
3	Area 3 Name	N
4	Area 4 Name	N
5	Area 5 Name	N
6	Area 6 Name	N
7	Area 7 Name	N
8	Area 8 Name	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Access > User Properties >

User Options	**MENU 1-4-2**

1	Master User	Y
2	Reserved	N
3	Arm Only	N
4	Can Bypass	Y
5	Auto Bypass Allowed	Y
6	Always Report Op/Cl	Y
7	Reserved	N
8	Log Credential	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Copyright © 2002-2022 Digflex Pty Ltd

Access > User Properties >

TimeZone Access — MENU 1-4-4

0	1

00 - Disabled
01 - 24 Hour TimeZone
02 - TimeZone 2 Name
03 - TimeZone 3 Name
04 - TimeZone 4 Name
05 - TimeZone 5 Name
06 - TimeZone 6 Name
07 - TimeZone 7 Name
08 - TimeZone 8 Name
09 - TimeZone 9 Name
10 - TimeZone 10 Name
11 - TimeZone 11 Name
12 - TimeZone 12 Name
13 - TimeZone 13 Name
14 - TimeZone 14 Name
15 - TimeZone 15 Name
16 - TimeZone 16 Name

Enter 0 - 16 + [OK] to assign the user to a TimeZone – Can only be assigned to one TimeZone.

Note

All users are assigned to TimeZone 1 by default. This means they have 24 hour access to the system. To restrict access. To restrict access to users, refer to TimeZones.

Access > User Properties >

Door Assignment — MENU 1-4-5

1	Door 1 Name	N
2	Door 2 Name	N
3	Door 3 Name	N
4	Door 4 Name	N
5	Door 5 Name	N
6	Door 6 Name	N
7	Door 7 Name	N
8	Door 8 Name	N
9	Door 9 Name	N
10	Door 10 Name	N
11	Door 11 Name	N
12	Door 12 Name	N
13	Door 13 Name	N
14	Door 14 Name	N
15	Door 15 Name	N
16	Door 16 Name	N

Multiple doors can be assigned to each user. Press 1 – 16, then press [ON] or [OFF] to toggle door on/off, then press [OK] to save.

Access > User Properties >

User Expire Date — MENU 1-4-6

Access > Global Properties >

PIN Length — MENU 1-5-0

(*** System Wide Parameter ***)

0	4

00 - Variable
01 - 1 Digit
02 - 2 Digits
03 - 3 Digits
04 - 4 Digits
05 - 5 Digits
06 - 6 Digits
07 - 7 Digits
08 - 8 Digits

Enter 00 - 08 + [OK] to program the PIN length.

Access > Global Properties >

PIN Retry Count — MENU 1-5-1

(*** System Wide Parameter ***)

0	6

Use [↑] and [↓] keys or enter 00 – 15 + [OK] to program the PIN retry count (00 = Unlimited).

Access > Global Properties >

Installer PIN — MENU 1-5-2

1	2	3	4	A	A	A	A

(*** System Wide Parameter ***)
Use [0] – [9] keys to program the installer PIN + [OK] to save. Installer PIN can be up to 8 digits long.

Access > Reporting

Access Route — MENU 1-6-0

0	0

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK]. Enter single option only. (*** System Wide Parameter ***).

Access > Reporting >

Access Options — MENU 1-6-1

1	Access Granted	Y
2	Access Denied	Y
3	Egress Granted	Y
4	Egress Denied	Y
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Copyright © 2002-2022 Digflex Pty Ltd

Access > Fingerprint >

Add Fingerprint **MENU 1-8-0**

Access > Fingerprint >

Delete Fingerprint **MENU 1-8-1**

Access > Fingerprint >

Fingerprint Status **MENU 1-8-2**

Area Programming

By default the control panel is configured for one area. Examples given in this document are for Area 1 only. If the system is configured for more than one area then you will be prompted on the keypad to select the area you want to work on.

Areas > Commands >

Area Status **MENU 2-0-0**

Turn Area On/Off **MENU 2-0-1**

Turn All Areas On **MENU 2-0-2**

Turn All Areas Off **MENU 2-0-3**

Move To Area **MENU 2-0-4**

Chime On/Off **MENU 2-0-5**

Chime Mode **MENU 2-0-6**

Areas > Area Properties >

Area Name **MENU 2-1-0**

S	e	c	u	r	i	t	y		S	y	s	t	e	m					

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Areas > Properties >

General Options **MENU 2-1-1**

1	Exit Time Restart	N
2	Reset Alarm Memory	N
3	Duress Allowed	Y
4	Fault ACK Required	N
5	One Key Arming	Y
6	One Key Part On	Y
7	Link To Common Area	N
8	One Key Part Off	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Areas > Properties >

Input Options **MENU 2-1-2**

1	Non Sequential	Y
2	Pulse Count H/Over	Y
3	Senior Watch	N
4	Reset Smoke On Arming	Y
5	Senior Watch In Minute	N
6	Reserved	N
7	Reserved	N
8	Auto Arm In Part 1	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Areas > Properties >

Output Options **MENU 2-1-3**

1	SPK Beeps Keyfob	Y
2	SPK Beeps Key/Sw	Y
3	SPK Strobe In Part On	Y
4	Alarm On PIN Retry	Y
5	Alarm Exit Error	N
6	Alarm Key/Sw Tamper	Y
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Areas > Properties >

Reporting Options **MENU 2-1-4**

1	Report PIN Retry	Y
2	Report Exit Error	Y
3	Smart Lockout	N
4	Reserved	N
5	Cancel Report	Y
6	Reserved	N
7	Op/Cl In Part On	N
8	Op/Cl After Alarm	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Copyright © 2002-2022 Digflex Pty Ltd

Areas > Properties >

Strobe Trigger — MENU 2-1-5

1	Audible Burglary	Y
2	Silent Burglary	N
3	Fire Alarm	Y
4	Keyfob On/Off	N
5	Keyswitch On/Off	N
6	Reserved	N
7	24Hr Alarm	Y
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Areas > Area Properties >

Part Mode 1 Name — MENU 2-1-6

P	a	r	t		1		A	r	e	a		1		N	a	m	e

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Areas > Area Properties >

Part Mode 2 Name — MENU 2-1-7

P	a	r	t		2		A	r	e	a		1		N	a	m	e

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Areas > Area Properties >

Auto Arming — MENU 2-1-8

0	0

00 - Disabled
01 - 24 Hour TimeZone
02 - TimeZone 2 Name
03 - TimeZone 3 Name
04 - TimeZone 4 Name
05 - TimeZone 5 Name
06 - TimeZone 6 Name
07 - TimeZone 7 Name
08 - TimeZone 8 Name
09 - TimeZone 9 Name
10 - TimeZone 10 Name
11 - TimeZone 11 Name
12 - TimeZone 12 Name
13 - TimeZone 13 Name
14 - TimeZone 14 Name
15 - TimeZone 15 Name
16 - TimeZone 16 Name

Enter 0 - 16 + [OK] to assign the area to a TimeZone – Can only be assigned to one TimeZone (0 = Disabled). To set the start/stop and days of the week that the area will automatically arm, refer to TimeZone menu's.

Areas > Reporting >

Account Dest 1 — MENU 2-2-0

0	0	0	0	0	0	0	0	0	0

Program the area account number for Destination 1 here (Enter digits 0 – 9 + [OK] to save).

Areas > Reporting >

Account Dest 2 — MENU 2-2-1

0	0	0	0	0	0	0	0	0	0

Program the area account number for Destination 1 here (Enter digits 0 – 9 + [OK] to save).

Areas > Reporting >

Open Close Route — MENU 2-2-2

0	1

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK] to program which destination 'Open' and 'Close' reports are sent to.

Areas > Timers >

Exit Time — MENU 2-8-0

0	6	0

Seconds

Enter 000 – 255 + [OK] to program the exit time in seconds.

Areas > Timers >

Entry Time 1 — MENU 2-8-1

0	2	0

Seconds

Enter 000 - 255 + [OK] to program the entry time in seconds.

Areas > Timers >

Entry Time 2 — MENU 2-8-2

0	4	0

Seconds

Enter 000 - 255 + [OK] to program the entry time in seconds.

Areas > Timers >

Part Entry Time — MENU 2-8-3

0	6	0

Seconds

Enter 000 - 255 + [OK] to program the part entry time in seconds.

Copyright © 2002-2022 Digflex Pty Ltd

Areas > Timers >

Auto Arm Pre Alert — MENU 2-8-4

(*** System Wide Parameter ***) [0][1][0]

Minutes

Enter 000 – 255 + [OK] to program the pre-alert time in minutes (0 = No Pre-Alert).

Areas > Timers >

Senior Watch Time — MENU 2-8-6

(*** System Wide Parameter ***) [0][0][0]

Hours

Enter 000 – 255 + [OK] to program the senior watch interval in hours.

Areas > Area Testing >

Area Watch — MENU 2-9-0

(*** System Wide Parameter ***) [0][1][2]

Weeks

Enter 000 – 255 + [OK] to program the number of weeks before registering an inactivity event.

Areas > Area Testing >

User Test Interval — MENU 2-9-1

(*** System Wide Parameter ***) [0][0][0]

Days

Enter 000 – 255 + [OK] to program the number of days before a user test is requested.

Areas > Area Testing >

Service Interval — MENU 2-9-2

(*** System Wide Parameter ***) [0][0][0]

Weeks

Enter 000 – 255 + [OK] to program the number of weeks required between installer services.

Areas > Area Testing >

Test Options — MENU 2-9-3

1	User Test Required	Y
2	Reserved	N
3	Reserved	N
4	Reserved	N
5	Reserved	N
6	Walk Test Report	Y
7	Walk Test 24Hr	N
8	Walk Test Fire	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Input Programming

Inputs > Commands >

Zone Status — MENU 3-0-0

Zone Array — MENU 3-0-1

Bypass Zones — MENU 3-0-2

Set Chime Zones — MENU 3-0-3

Set Part 2 Zones — MENU 3-0-4

Smoke Sensor Reset — MENU 3-0-5

Inputs > Zone Properties >

Zone Name — MENU 3-1-0

[Z][o][n][e][ ][1][ ][N][a][m][e][ ][ ][ ][ ][ ][ ][ ][ ][ ]

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Inputs > Zone Properties >

Zone Type — MENU 3-1-1

[0][1]

00 - Not Used	08 - Hold Up 24Hr
01 - Burglary Delay 1	09 - Medical 24Hr
02 - Burglary Delay 2	10 - Panic 24Hr
03 - Burglary Instant	11 - Fire 24Hr
04 - Burg Inst No Exit	12 - Not Used
05 - Burg Handover	13 - Keyswitch Zone
06 - Burglary 24Hr	14 - Display Only
07 - Tamper 24Hr	15 - Non Burglary 24Hr

Use [↑] and [↓] keys or enter 0 – 15 + [OK] to program the zone type.

Inputs > Zone Properties >

Area Assignment — MENU 3-1-2

[0][1]

00 - No Area	
01 - Security System	05 - Area 5 Name
02 - Area 2 Name	06 - Area 6 Name
03 - Area 3 Name	07 - Area 7 Name
04 - Area 4 Name	08 - Area 8 Name

Use [↑] and [↓] keys or enter 0 - 8 then press [OK] to program.

Copyright © 2002-2022 Digflex Pty Ltd

Zone Assignments

Zone Assignment Table									
Module Number	Address Setting SW1	SW2	SW3	SW4	SW5	Zone Numbers (Single EOL)	Zone Numbers (Alarm+Tamper EOL)	Zone Numbers (Split EOL)	Single or Alarm + Tamper EOL With CM705 + CM707 Module
Control Panel						1 to 8	1 to 8	1 to 16	1 to 8
1 =	OFF	OFF	OFF	OFF	OFF	17 to 24	17 to 24	17 to 32	17 to 24 25 to 32 on the CM707
2 =	ON	OFF	OFF	OFF	OFF	33 to 40	33 to 40	33 to 48	33 to 40 41 to 48 on the CM707
3 =	OFF	ON	OFF	OFF	OFF	49 to 56	49 to 56	49 to 64	49 to 56 57 to 64 on the CM707
4 =	ON	ON	OFF	OFF	OFF	65 to 72	65 to 72	65 to 80	65 to 72 73 to 80 on the CM707
5 =	OFF	OFF	ON	OFF	OFF	81 to 88	81 to 88	81 to 96	81 to 88 89 to 96 on the CM707
6 =	ON	OFF	ON	OFF	OFF	97 to 104	97 to 104	97 to 112	97 to 104 105 to 112 on the CM707
7 =	OFF	ON	ON	OFF	OFF	113 to 120	113 to 120	113 to 128	113 to 120 121 to 128 on the CM707
8 =	ON	ON	ON	OFF	OFF	129 to 136	129 to 136	129 to 144	129 to 136 137 to 144 on the CM707

Table 16: Zone Assignments

Inputs > Zone Properties >

Pulse Count — MENU 3-1-3

Pulses [0][0]

00 - No Pulse Count
01 - 1 Pulse
02 - 2 Pulses
03 - 3 Pulses
04 - 4 Pulses
05 - 5 Pulses
06 - 6 Pulses Inertia
07 - 7 Pulses Inertia
08 - 8 Pulses Inertia
09 - 9 Pulses Inertia
10 - 10 Pulses Inertia
11 - 11 Pulses Inertia
12 - 12 Pulses Inertia
13 - Door Open Too Long
14 - PreDelay
15 - Reserved

Enter 0 – 15 + [OK] to program the number of pulses the zone must register within the zone pulse count time.

Inputs > Zone Properties >

Pulse Count Time — MENU 3-1-4

Seconds [1][2][0]

000 to 255 - No Of Seconds

Enter 0 – 255 + [OK] to program the period of time in seconds that the pulse count must register.

Inputs > Zone Properties >

Door Assignment — MENU 3-1-5

[0][0]

00 - Disabled
01 - Door 1 Name
02 - Door 2 Name
03 - Door 3 Name
04 - Door 4 Name
05 - Door 5 Name
06 - Door 6 Name
07 - Door 7 Name
08 - Door 8 Name
09 - Door 9 Name
10 - Door 10 Name
11 - Door 11 Name
12 - Door 12 Name
13 - Door 13 Name
14 - Door 14 Name
15 - Door 15 Name
16 - Door 16 Name

A single door can be assigned to each zone. Use the [↑] and [↓] keys to highlightdoor name, then press [OK] to save.

Inputs > Zone Properties >

Report Route — MENU 3-1-6

[0][1]

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK] to set the destination zone reports are sent to.

Copyright © 2002-2022 Digflex Pty Ltd

Zone Default Table

The table below list the default values for all zone parameters in the Vision-XIP. By default, zones 5 to 16 are set as Instant zones and zones 17 to 144 are set as Not Used. Zones marked as Not Used do not require EOL resistors to be fitted.

Programming	Zone 1	Zone 2	Zone 3	Zone 4	Zones 5 - 16	Zones 17 - 144
Zone Name	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5 to 16	Zone 17 to 144
Zone Type	1 = Delay 1	5 = Handover	5 = Handover	5 = Handover	3 = Instant	0 = Not Used
Area Assignment	1	1	1	1	1	1
Pulse Count	0	0	0	0	0	0
Pulse Count Time	120	120	120	120	120	120
Door Assignment	0	0	0	0	0	0
Report Route	2	2	2	2	2	2
Reporting Options						
Lockout Dialler	Y	Y	Y	Y	Y	Y
Report Alarm	Y	Y	Y	Y	Y	Y
Report Troubles	Y	Y	Y	Y	Y	Y
Report Bypass	Y	Y	Y	Y	Y	Y
Report Restores	Y	Y	Y	Y	Y	Y
Delay Reporting	N	N	N	N	N	N
Zone Options						
Lockout Siren	Y	Y	Y	Y	Y	Y
Silent Alarm	N	N	N	N	N	N
Inverted Seal	N	N	N	N	N	N
Bypass Allowed	Y	Y	Y	Y	Y	Y
Sensor Watch	N	N	N	N	N	N
Armed In Part On	Y	Y	Y	Y	Y	Y
No EOL Required	N	N	N	N	N	N
Test On Exit	Y	Y	Y	Y	Y	Y

Table 17: Zone Defaults

Inputs > Zone Properties >

Report Options **MENU 3-1-7**

1	Lockout Dialler	Y
2	Report Alarm	Y
3	Report Troubles	Y
4	Report Bypass	Y
5	Reserved	N
6	Reserved	N
7	Report Restores	Y
8	Delay Reporting	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Inputs > Zone Properties >

Zone Options **MENU 3-1-8**

1	Lockout Siren	Y
2	Silent Alarm	N
3	Inverted Seal	N
4	Bypass Allowed	Y
5	Sensor Watch	N
6	Armed In Part On	Y
7	No EOL Required	N
8	Test On Exit	Y

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Inputs > RF Zone >

Add RF Device **MENU 3-3-0**

Delete RF Device **MENU 3-3-1**

Test RF Device **MENU 3-3-2**

Copyright © 2002-2022 Digflex Pty Ltd

Gross Attack — MENU 3-3-3-0

Minor Attack — MENU 3-3-3-1

Inputs > RF Zone > RF Zone Properties >

Zone Options — MENU 3-3-3-3

1	Enable Rear Tamper	N
2	Enable Case Tamper	N
3	Reserved	N
4	Reserved	N
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Inputs > Global Input Options >

EOL Value — MENU 3-4-0

(*** System Wide Parameter ***) 0 5

00 - No EOL
01 - 1k0 Ohm
02 - 1k5 Ohm
03 - 2k2 Ohm
04 - 2k7 Ohm
05 - 3k3 Ohm
06 - 4k7 Ohm
07 - 5k6 Ohm
08 - 6k8 Ohm
09 - 8k1 Ohm
10 - 10k Ohm
11 - 6K8 Alarm + 2k2 Tamp
12 - 10k Alarm + 10k Tamp
13 - 22k Ohm
14 - 3k3 Alarm + 6k8 Tamp
15 - Split EOL 3k3 //6k8

Use [↑] and [↓] keys or enter 0 - 15, then press [OK] to program globally the EOL resistor for all zones.

Inputs > Global Input Options >

Keyswitch Options — MENU 3-4-1

(*** System Wide Parameter ***) 0 0

00 - Latching All On/Off
01 - Latching All On
02 - Latch Part On/Off
03 - Latching Part On
04 - Latching Off
05 - Pulse All On/Off
06 - Pulse All On
07 - Pulse Part On/Off
08 - Pulse Part On
09 - Pulse Part Off

Use [↑] and [↓] keys or enter 0 - 9, then press [OK] to program how the keyswitch will operate.

Inputs > Global Input Options >

Input Options — MENU 3-4-2

1	Tamper On Short	N
2	Reserved	N
3	Response Time 500msec	N
4	Reserved	N
5	Keyswitch Open Close	Y
6	Alarm On Tamper	N
7	Reserved	N
8	Reserved	N

(*** System Wide Parameter ***)

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Inputs > PGM Input >

Keyswitch Options — MENU 3-5-0

0 0

00 - Disabled
01 - Latching On/Off
02 - Pulse On/Off
03 - Simple RF On/Off
04 - Bosch Serial Rcvr
05 - Crow Serial Rcvr (TBA)

Enter 0 - 8 + [OK] to select the interface method used for the given RF receiver.

Inputs > Tamper Inputs >

Tamper Options — MENU 3-6-0

1	Display Panel Tpr	Y
2	Report Panel Tpr	Y
3	Audible Panel Tpr	Y
4	Display Expander Tpr	Y
5	Report Expander Tpr	Y
6	Audible Expander Tpr	Y
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Inputs > Input Testing >

Walk Test All Zones — MENU 3-9-0

Inputs > Input Testing >

Walk Test A Zones — MENU 3-9-1

Copyright © 2002-2022 Digflex Pty Ltd

Inputs > Input Testing >

Sensor Watch Time **MENU 3-9-2**

(*** System Wide Parameter ***) [0][3][0] Days

Enter 0 – 255 + [OK] to program the sensor watch time in days (0 = Disabled).

Output Programming

Outputs > Commands >

Output Status **MENU 4-0-0**

Turn Output On/Off **MENU 4-0-1**

Output Array **MENU 4-0-2**

Door Status **MENU 4-0-3**

Door Array **MENU 4-0-4**

Door Control **MENU 4-0-5**

Macro Array **MENU 4-0-6**

Outputs > Properties >

Output Name **MENU 4-1-0**

[O][u][t][p][u][t][ ][1][ ][N][a][m][e][ ][ ][ ][ ][ ][ ][ ]

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Outputs > Properties >

Event Type **MENU 4-1-1**

[0][0][0]

Use [↑] and [↓] keys or enter desired event type 0 – 255 + [OK]. See output event type table for available options.

Output Default Table

The table below list the default values for all Output parameters in the control panel. Outputs 1 to 4 are High current digital outputs and Output 5 is the onboard relay output. Outputs 9 to 40 are only available if the optional modules are fitted. Options marked N/A = Not Applicable.

Programming Option	Output 1	Output 2	Output 3	Output 4	Output 5	Output 9 - 40
Output Name	External Siren	Strobe Light	Smoke Sensor PWR	Internal Siren	On Board Relay	Output x Name
Event Type	36 (External Siren)	48 (Strobe)	49 (Smoke Sensor GND)	37 (Internal Siren)	54 (Keyfob Function 2)	00 (Not Used)
Event Assignment	0	0	0	0	0	0
Output Polarity	14 Speaker Output	6 1 Shot Low + Reset	11 Low 1 Shot Open	6 1 Shot Low + Reset	4 Open 1 Shot Low	0 Open To Low
Time Parameter						
N° Of Hours	000	008	000	000	000	000
N° Of Minutes	005	000	000	005	000	000
N° Of Seconds	000	000	010	000	002	000
N° Of 1/10 Seconds	000	000	000	000	000	000
Output Options						
Off On Low Battery	Y	Y	N	Y	N	N
Guest Control	N	N	N	N	N	N
Reserved	N	N	N	N	N	N
Monitor Overload	Y	Y	Y	Y	N	N
Report Device Fail	Y	Y	N	Y	N	N
Alarm On Device Fail	N	N	N	N	N	N
Block If All On	N	N	N	N	N	N
Show Status On Keypad	N	N	N	N	N	N

Table 18: Output Default Table

Copyright © 2002-2022 Digflex Pty Ltd

Output Event Types

00 - Disabled	P	26 - Entry Timing	A	52 - Exit Error	A
01 - Battery Trouble	P	27 - Exit Timing	A	53 - Keyfob Function 1	A
02 - Reserved	P	28 - End Of Exit Time	A	54 - Keyfob Function 2	A
03 - Telco Line Fail	P	29 - Chime On	A	55 - Output In PreDelay	Op
04 - Comm Fail	Rr	30 - Chime Zone Trigger	A	56 - Follow PIN Code	Ur
05 - Reserved	Rr	31 - Auto Arm Pre Alert	A	57 - Part Entry Time	A
06 - Dest Reporting	Rr	32 - Ready To Arm All On	A	58 - TimeZones	Tz
07 - Disabled		33 - Ready To Part Arm	A	59 - Temperature Hi/Lo	Kp
08 - Dest Kiss Off	Rr	34 - Ready To Part 2 Arm	A	60 - Door	Dr
09 - User Keyfob Func 1	Ur	35 - Close Sent OK	A	61 - Door Open Too Long	Dr
10 - User Keyfob Func 2	Ur	36 - External Audible	A	62 - Door Bell	A
11 - Dialler Disabled	P	37 - Internal Audible	A	63 - Zone Bypass	Zn
12 - Output Device Missing	P	38 - Any Zone Alarm	A	69 - User Control	Ur
13 - Output Trouble	Op	39 - Fire Alarm	A	70 - User Panic	Ur
14 - Reserved	P	40 - Burglary Alarm	A	71 - CLI Trigger	CLI
15 - Incoming Call	P	41 - Silent Alarm	A	72 - GSM Signal Lost	P
16 - System Trouble	P	42 - Duress Alarm	A	73 - GPRS Failure	P
17 - Box Tamper	Zn	43 - Keypad Medical	A	74 - Ethernet Fail	P
18 - Zone Trouble	Zn	44 - Keypad Fire	A	75 - Macro	Ma
19 - Zone Mirror	Zn	45 - Keypad Panic	A		
20 - Zone Alarm	A	46 - Device Tamper	A		
21 - Area Disarmed	A	47 - Access Denied	A		
22 - Area Part Or All On	A	48 - Strobe	A		
23 - Area All On	A	49 - Smoke Sensor GND	A		
24 - Area Part On	A	50 - Sensor Watch	A		
25 - Area Part 2 On	A	51 - Senior Watch	A		

Legend:		
(Ma) = Macro	(CLI) = CLI Trigger Table	(A) = Area Event Assignment
(P) = Panel Event Assignment	(Op) = Output Event Assignment	(Zn) = Zone Event Assignment
(Ur) = User Event Assignment	(Tz) = TimeZone Event Assignment	(Dr) = Door Group Event Assignment
(Kp) = Keypad	(Rr) = Reporting Destination	

Table 19: Output Event Types

Copyright © 2002-2022 Digflex Pty Ltd

Output Assignments

Output Assignments						
Module Number	Address Setting					Output Number
	SW1	SW2	SW3	SW4	SW5	
Control Panel						1 to 5
Virtual Outputs						6 to 8
1 =	OFF	OFF	OFF	OFF	OFF	9 to 12
2 =	ON	OFF	OFF	OFF	OFF	13 to 16
3 =	OFF	ON	OFF	OFF	OFF	17 to 20
4 =	ON	ON	OFF	OFF	OFF	21 to 24
5 =	OFF	OFF	ON	OFF	OFF	25 to 28
6 =	ON	OFF	ON	OFF	OFF	29 to 32
7 =	OFF	ON	ON	OFF	OFF	33 to 36
8 =	ON	ON	ON	OFF	OFF	37 to 40

Table 20: Address Configuration and Output Assignments

Outputs > Properties >

Event Assignment — MENU 4-1-2

0 0 0

(A) = Area Assignment
Assign to Area 1 to 8 (0 = Any Area)

(P) = Control Panel

(Op) = Output Assignment
Assign to Output 1 to 40 (0 = Any Output)

(Zn) = Zone Assignment
Assign to Zone 1 to 144 (0 = Any Zone)

(Ur) = User Assignment
Assign to User 1 to 255 (0 = Any User)

(Tz) = TimeZone Assignment
Assign to TimeZone 1 to 16 (0 = Any TimeZone)

(Dr) = Door Assignment
(Assign to Door Assignment 1 to 16 (0 = Any Door)

(Kp) = Keypad Assignment
Assign to Keypad/LAN Reader 1 to 16 (0 = Any Keypad/LAN Reader)

(Rr) = Reporting Destination
Assign to Destination 1 or 2 (0 = Destination 1 and/or Destination 2)

(Ma) = Macro Group Assignment
Assign to Macro Group (0 = Any Macro Group)

(CLI) = CLI Trigger Table
Assign to CLI Trigger Table 1 or 2 (0 = Both Tables)

Use [↑] and [↓] keys to program which Area, User, Zone, Keypad or Access Group Number etc you want the output to follow then press [OK].

Outputs > Properties >

Output Polarity — MENU 4-1-3

0 0

00 - Open To Low
01 - Open To Low + Pre
02 - Open Latching Low
03 - Open Pulsing Low
04 - Open 1 Shot Low
05 - 1 Shot Low+Retrigger
06 - 1 Shot Low + Reset
07 - Low To Open
08 - Low To Open + Pre
09 - Low Latching Open
10 - Low Pulsing Open
11 - Low 1 Shot Open
12 - 1 Shot Open+Retrigger
13 - 1 Shot Open + Reset
14 - Speaker Output
15 - Toggle

Enter 0 – 15 + [OK] to program the output polarity type. Each output can only have one polarity type programmed.

Outputs > Properties >

Time Parameter — MENU 4-1-4

Hour	Minute	Seconds	10th Sec
0 0 0	0 0 0	0 0 0	0 0 0

The time base parameter is only applicable for output types that are programmed as one shot or pulsing. Program 0 to 255 for each of the units (Hour, Minute, Seconds and 10th of a second) for the time parameter. Add the units together to give the total one shot time or pulsing on/off time.

One Shot Mode

The time base is the length of time that the output will operate.

For example, you may want a strobe output to operate for 1 hour, Either of the examples below will achieve the 1 hour time.

Total Time	Hour	Minute	Seconds	10th Sec
60 Minutes	001	000	000	000
60 Minutes	000	060	000	000

Table 21: One-Shot Polarity Example

Pulsing Mode

The time base is the unit of time that the output will pulse on and off. If the time base is programmed for 60 seconds, the output will pulse on for 60 seconds and then off for 60 seconds (repeat) until the output is reset.

Copyright © 2002-2022 Digflex Pty Ltd

Outputs > Properties >

Output Options **MENU 4-1-5**

1	Off On Low Battery	Y
2	Guest Control	N
3	Reserved	N
4	Monitor Overload	Y
5	Monitor Device Fail	Y
6	Alarm On Device Fail	N
7	Block If All On	N
8	Show Status On Keypad	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Door Properties

Outputs > Door Properties >

Door Name **MENU 4-2-0**

D	o	o	r		1		N	a	m	e								

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Outputs > Door Properties >

Unlock TimeZone **MENU 4-2-2**

0	0

00 - Disabled
01 - 24 Hour TimeZone
02 - TimeZone 2 Name
03 - TimeZone 3 Name
04 - TimeZone 4 Name
05 - TimeZone 5 Name
06 - TimeZone 6 Name
07 - TimeZone 7 Name
08 - TimeZone 8 Name
09 - TimeZone 9 Name
10 - TimeZone 10 Name
11 - TimeZone 11 Name
12 - TimeZone 12 Name
13 - TimeZone 13 Name
14 - TimeZone 14 Name
15 - TimeZone 15 Name
16 - TimeZone 16 Name

A single TimeZone can be assigned to each door. Use the [↑] and [↓] keys to highlight door name, then press [OK] to select. Enter 0 - 16 + [OK] to assign the door to a TimeZone – can only be Assigned to one TimeZone (0 = Disabled).

Outputs > Door Properties >

Door Options **MENU 4-2-3**

1	Hold Off If Area Armed	Y
2	Hold Off Auto Unlock	N
3	Reserved	N
4	Report Door Forced	N
5	Alarm Door Forced	N
6	Report DOTL	N
7	Alarm On DOTL	N
8	Lift Door	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

RF Outputs

Outputs > RF Output >

Add RF Device **MENU 4-3-0**

Delete RF Device **MENU 4-3-1**

Test RF Device **MENU 4-3-2**

Copyright © 2002-2022 Digflex Pty Ltd

Macros and Scenes

Outputs > Macros >

Name **MENU 4-8-0**

Macros 1 Name

Outputs > Macros >

Macro Rule **MENU 4-8-1**

Script Character	Character Represents
O	Output
A	Area
M	Macro
T	TimeZone
H	Holiday
Z	Zone
D	Door
Version 2.30 adds macro support for keypad hold down functions on the arrow keys.	
K#U	Keypad Up Arrow
K#D	Keypad Down Arrow
K#L	Keypad Left Arrow
K#R	Keypad Right Arrow
The '#' symbol represents the keypad address number	

Operator Character	Operator Meaning
&	And
|	Or
!	Inverted Function

Outputs > Macros >

Scene **MENU 4-8-2**

Script Character	Character Represents
O	Output
D	Door
A	Area
P	Part 1
Q	Part 2
Z	Zone Bypass
M	Macro (TBA)
C	Countdown

Operator Character	Operator Meaning
&	And
|	Or
!	Inverted Function

Outputs > Output Testing >

External Siren Test **MENU 4-9-0**

Internal Siren Test **MENU 4-9-1**

Strobe Test **MENU 4-9-2**

Fire Siren Test **MENU 4-9-3**

Copyright © 2002-2022 Digflex Pty Ltd

Comms Programming

Start Direct Link — MENU 5-0-5

Comms > Commands >

Register Customer — MENU 5-0-8

This menu is used to enter the customer registration number into the control panel. This unique 11 digit number is generated by the system owner when they create an account on the MyAlarm web site.

Comms > Commands >

Register Installer — MENU 5-0-9

This menu is used to enter the installer registration number into the control panel. This unique 11 digit number is generated by the installer when they create an installer account on the MyAlarm Web site.

This number should be entered into all panels installed by the installer allowing them to view all their panels via the MyAlarm web site.

Comms > Properties >

Report Options — MENU 5-2-1

1	Reserved	N
2	Reserved	N
3	Reserved	N
4	Reserved	N
5	Mirror Reports To Web	N
6	Reserved	N
7	Reserved	N
8	Abort Failed Reports	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Comms > Properties >

Country — MENU 5-2-3

(*** System Wide Parameter ***) [0][1]


Ln1 AUSTRALIA	Ln9 CZECH REPUBLIC
Ln2 NEW ZEALAND	Ln10 POLAND
Ln3 ITALY	Ln11 TURKEY
Ln4 GREECE	Ln12 CHINA
Ln5 CYPRUS	Ln13 HONG KONG
Ln6 SPAIN	Ln14 MALAYSIA
Ln7 PORTUGAL	Ln15 BRAZIL
Ln8 HUNGARY	

This menu automatically sets the dialling parameters including dial and busy tones etc. for the country the panel is working in.

1. Press [MENU] + [5] + [2] + [3]. The keypad will display the currently selected country. The default country is Australia.
2. Use the up and down arrow keys to select the appropriate country then press [OK].



3. Press [OK] to confirm and save and exit or press [MENU] to exit without saving.



Comms > Remote Access >

RAS Security PIN — MENU 5-3-1

[1][2][3][4][5][6][7][8]

Use keys [0] - [9] to program RAS Security PIN + [OK] to save.

Comms > Remote Access >

Log Threshold — MENU 5-3-2

[7][0] %

Enter 0 - 9 to program log threshold + [OK] to save.

Comms > Remote Access >

User RAS PIN — MENU 5-3-8

[0][0][0][0][0][0][0][0]

Use keys [0] - [9] to program User RAS Security PIN + [OK] to save.

Copyright © 2002-2022 Digflex Pty Ltd

Comms > Reporting >

TX Format Dest 1 — MENU 5-4-0

[0][0]

00 - Disabled
0 ~ 12 - Reserved
13 - Ethernet/Wifi
14 - GPRS IP
15 - MyAlarm IP

Use [↑] and [↓] keys or enter 0 – 15 then press [OK] to program the transmission format the control panel will use to report to Destination 1. Only 1 option can be programmed.

Comms > Reporting >

TX Format Dest 2 — MENU 5-4-1

[0][0]

00 - Disabled
0 ~ 12 - Reserved
13 - Ethernet/Wifi
14 - GPRS IP
15 - MyAlarm IP

Use [↑] and [↓] keys or enter 0 – 15 then press [OK] to program the transmission format the control panel will use to report to Destination 2. Only 1 option can be programmed.

Comms > Reporting

Test Route — MENU 5-4-2

[0][1]

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK]. Enter single option only. (*** System Wide Parameter ***).

Comms > Reporting

System Route — MENU 5-4-3

[0][1]

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK]. Enter single option only. (*** System Wide Parameter ***).

Comms > Reporting

Emergency Route — MENU 5-4-4

[0][1]

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK]. Enter single option only. (*** System Wide Parameter ***).

Comms > Reporting >

Swinger Dialler — MENU 5-4-5

(*** System Wide Parameter ***) [0][6]

Enter 0 – 15 + [OK] to program number of times the dialler can report before lockout. 0 = Unlimited.

Comms > Reporting >

Burg Report Delay — MENU 5-4-6

(*** System Wide Parameter ***) [0][0][0] **Seconds**

Enter 0 – 255 seconds + [OK] to program the delay time in seconds before reports are sent. 0 = No Delay.

Comms > Reporting >

Fire Report Delay — MENU 5-4-7

(*** System Wide Parameter ***) [0][0][0] **Seconds**

Enter 0 – 255 seconds + [OK] to program the delay time in seconds before reports are sent. 0 = No Delay.

Copyright © 2002-2022 Digflex Pty Ltd

Comms > MyAlarm >

IP Address — MENU 5-5-0

	1			Digits						12		
Primary	0	5	2	0	6	4	0	1	7	0	5	4
Second-ary	0	1	3	0	5	5	0	0	0	2	4	1

Factory Set

Comms > MyAlarm >

IP Port — MENU 5-5-1

Primary	0	9	0	5	0
Secondary	0	9	0	5	1

Factory Set

Comms > MyAlarm >

MyAlarm Options — MENU 5-5-2

1	Display Eth/WiFi Poll Fail	N
2	Rpt Eth/WiFi Poll Fail	N
3	Disp Cellular Poll Fail	N
4	Rpt Cellular Poll Fail	N
5	Disable Eth/WiFi MyAlar	N
6	Reserved	N
7	Reserved	N
8	Static IP	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Note

Menu's 5-5-0 and 5-5-1 should be left at the factory default settings unless you are advised otherwise by the manufacturer.

Comms > IP Reporting >

Receiver IP — MENU 5-6-0

	1			Digits						12		
Dest Nº 1	0	0	0	0	0	0	0	0	0	0	0	0
Dest Nº 2	0	0	0	0	0	0	0	0	0	0	0	0

Use [←] and [→] keys to scroll cursor, enter 0 – 9 for IP address digits and press [OK] to save when finished.

Comms > IP Reporting >

Receiver Port — MENU 5-6-1

Dest Nº 1	0	7	7	0	0
Dest Nº 2	0	7	7	0	0

Enter base station port number - must be 5 digits within the range 0 to 65535. Use [←] and [→] keys to scroll cursor. Press [OK] to save.

Comms > IP Reporting >

Poll Rate — MENU 5-6-2

0	3	6	0

Seconds x10

Enter 0000 - 9999 + [OK] to program the poll rate time in seconds (x10) for both Destination 1 and/or Destination 2.

Comms > IP Reporting >

ACK Wait Time — MENU 5-6-3

0	1	0

Seconds

Enter 0 - 255 + [OK] to program the acknowledge wait time in seconds for both Destination 1 and/or Destination 2.

Comms > IP Reporting >

IP Format — MENU 5-6-4

0	1

00 - Conettix
01 - Conettix NNC (Anti Replay)
02 - CSV IP ALARM
03 - SIA UDP
04 - SIA
05 - Reserved
06 - CSV IP UDP
07 - Reserved

Enter 0 - 7 + [OK] to program the IP format for both Destination 1 and/or Destination 2.

Copyright © 2002-2022 Digflex Pty Ltd

Comms > IP Reporting >

Retry Count — MENU 5-6-5

0 3

Enter 0 – 15 + [OK] to program the IP retry count (0 = No Retry) for both Destination 1 and/or Destination 2.

Comms > IP Reporting >

Encryption Key — MENU 5-6-6

1 Digits 32

Dest Nº 1 0 0 0 0 0 0 0 0 0 0 0

1 Digits 32

Dest Nº 2 0 0 0 0 0 0 0 0 0 0 0

The encryption key must match the encryption key on the base station receiver for communication to take place. To remove encryption set MENU-5-6-6 to all zeros.

Comms > IP Reporting >

Conettix NNC — MENU 5-6-7

Dest Nº 1 0 0 0 0 0 0 0 0

Dest Nº 2 0 0 0 0 0 0 0 0

The NNC number is used to prevent anti-replay attacks when reporting in Connetix format. The NNC number will be assigned by the control room at the time the account is setup. Like the account number the NNC will always be unique.

Comms > IP Reporting >

SIA IP Prefix — MENU 5-6-8

IP Account Dest Nº 1 1 Digits 16

0 0 0 0 0 0 0 0 0 0

IP Account Dest Nº 2 1 Digits 16

0 0 0 0 0 0 0 0 0 0

IP Account Prefix Dest Nº 1 1 Digits 6

0 0 0 0 0 0

IP Account Prefix Dest Nº 2 1 Digits 6

0 0 0 0 0 0

IP Receiver Prefix Dest Nº 1 1 Digits 6

0 0 0 0 0 0

IP Receiver Prefix Dest Nº 2 1 Digits 6

0 0 0 0 0 0

Highlight the parameter that you want to program, then press [OK] to select. Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Comms > IP Reporting >

User Name/Password — MENU 5-6-9

User Name 1 Digits 16

Password 1 Digits 16

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Comms > IP Reporting >

IP Reporting Options — MENU 5-6-1-0

1	Use SIA Format	N
2	SIA With Text	N
3	32 Bit Checksum	N
4	Reserved	N
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Comms > IP Remote Access >

IP Address — MENU 5-7-0

Installer 1 Digits 12

0 0 0 0 0 0 0 0 0 0 0 0

User 1 Digits 12

0 0 0 0 0 0 0 0 0 0 0 0

Use [←] and [→] keys to scroll cursor, use [0] – [9] keys to enter IP address, then press [OK] to save when finished.

Comms > IP Remote Access >

IP Port — MENU 5-7-1

Installer 0 7 7 0 1

User 0 7 7 0 1

Enter IP Port - must be 5 digits within the range 0 to 65535. Use [←] and [→] keys to scroll cursor. Press [OK] to save.

Copyright © 2002-2022 Digflex Pty Ltd

Comms > IP Remote Access >

IP RAS Options — MENU 5-7-2

1	IP RAS Allowed	Y
2	RAS Only If Disarmed	N
3	Report IP Session	Y
4	Report IP Lockout	Y
5	UDP Installer RAS	Y
6	UDP User RAS	N
7	Abort RAS On Alarm	Y
8	Allow User Functions	Y

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Comms > IP Remote Access >

RAS Lockout Time — MENU 5-7-3

0 6 0

Seconds

Enter 0 - 255 + [OK] to program the acknowledge wait time in seconds.

Comms > IP Remote Access >

IPRS Address — MENU 5-7-5

0 5 2 | 0 6 4 | 0 9 6 | 1 5 9

Reserved for factory use. Do not change unless requested to do so.

Comms > IP Remote Access >

IPRS Port — MENU 5-7-6

0 7 7 0 3

Reserved for factory use. Do not change unless requested to do so. Must be 5 digits within the range 0 to 65535.

Comms > Comms Test >

Send Test Report — MENU 5-9-0

Comms > Comms Test >

Test Report Time — MENU 5-9-1

Test Time

0 2 : 0 0

H H : M M

Use the [←] and [→] keys to move to the field then [↑] and [↓] to change. Press [OK] to save or [MENU] to exit without saving.

Note

Scroll through hours using the [↑] ***and*** [↓] ***to change from am to pm.***

Comms > Comms Test >

Test Report Period — MENU 5-9-2

(*** System Wide Parameter ***) 0 1

00 - No Test Report
01 - Every Day
02 - Every Week
03 - Every Month
04 - Every 2 Days
05 - Every 3 Days
06 - Every 4 Days
07 - Every 5 Days
08 - Reserved
09 - Reserved
10 - Reserved
11 - Reserved
12 - Reserved
13 - Reserved
14 - Every Hour
15 - Every 12 Hours

MENU 5-9-2 programs the interval between automatic test reports. Use [↑] and [↓] keys or enter [0] to [15] + [OK] to program.

Comms > Comms Test >

Test Report Options — MENU 5-9-3

1	Test If No Other Rpt	N
2	Test On Siren Reset	Y
3	Reserved	N
4	Reserved	N
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Comms > Reporting

Test Route — MENU 5-9-4

0 1

00 - Log Events Only
01 - Dest 1 + Log
02 - Dest 2 + Log
03 - Dest 1 & 2 + Log
04 - Dest 2 If 1 Fails

Use [↑] and [↓] keys or enter 0 - 4 + [OK]. Enter single option only. (*** System Wide Parameter ***).

Copyright © 2002-2022 Digflex Pty Ltd

Device Programming

Devices > Commands >

Device Status — MENU 6-0-0

LAN Secure — MENU 6-0-1

LAN Scan — MENU 6-0-2

LAN Watch — MENU 6-0-3

Keypad Volume — MENU 6-0-7

Keypad Contrast — MENU 6-0-8

Keypad Backlight — MENU 6-0-9

Devices > Keypads & Readers >

Name — MENU 6-1-0

K	e	y	p	a	d		1		N	a	m	e							

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Devices > Keypads & Readers >

Area Options — MENU 6-1-2

1	All On Arming Allowed	Y
2	Part On Arming Allowed	Y
3	Disarming Allowed	Y
4	Single Button Control	Y
5	All User Areas	N
6	Zero Exit Time	N
7	PIN To Change Area	N
8	Home Area Only	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Devices > Keypads & Readers >

Home Area — MENU 6-1-3

0	1

00 - No Area
01 - Security System
02 - Area 2 Name
03 - Area 3 Name
04 - Area 4 Name
05 - Area 5 Name
06 - Area 6 Name
07 - Area 7 Name
08 - Area 8 Name

Use [↑] and [↓] keys or enter 0 - 8 then press [OK] to program. This is the area that will be displayed on the keypad by default.

Note

All keypads must have a home area programmed to work correctly.

Devices > Keypads & Readers >

General Options — MENU 6-1-4

1	Enable Rear Tamper	N
2	Report Temperature	Y
3	Installer PIN Allowed	Y
4	Show Alarm When Armed	Y
5	Reader Area Control	Y
6	Reader Badging	N
7	Enable Egress Input	N
8	Log Egress Events	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Devices > Keypads & Readers >

Indicator Options — MENU 6-1-5

1	Extinguish	N
2	Greetings	Y
3	Display Temperature	N
4	Display Area Icons	N
5	Trouble Alert Beeps	Y
6	Entry Exit Warning	Y
7	Part Exit Warning	N
8	Chime Tone	Y

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Copyright © 2002-2022 Digflex Pty Ltd

Devices > Keypads & Readers >

Emergency Keys — MENU 6-1-6

1	Audible Keypad Fire	Y
2	Report Keypad Fire	Y
3	Audible Keypad Medical	Y
4	Report Keypad Medical	Y
5	Audible Keypad Panic	Y
6	Report Keypad Panic	Y
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Devices > Keypads & Readers >

Door Assignment — MENU 6-1-7

[0][0]

00 - No Door Assignment

01 - Door 1 Name	09 - Door 9 Name
02 - Door 2 Name	10 - Door 10 Name
03 - Door 3 Name	11 - Door 11 Name
04 - Door 4 Name	12 - Door 12 Name
05 - Door 5 Name	13 - Door 13 Name
06 - Door 6 Name	14 - Door 14 Name
07 - Door 7 Name	15 - Door 15 Name
08 - Door 8 Name	16 - Door 16 Name

A single door can be assigned to each keypad. Use the [↑] and [↓] keys to highlight door name, then press [OK] to save.

Devices > Keypads & Readers >

Lockout Time — MENU 6-1-8

(*** System Wide Parameter ***) [0][6][0]

Seconds

Enter 001 – 255 + [OK] to program the keypad lockout time in seconds. 000 = No Lockout.

Devices > Keypads & Readers >

WiFi Settings — MENU 6-1-9

SSID Scan
SSID
Security
Password
IP Address
Subnet Mask
Default Gateway
MAC Address
IP Options

Devices > RF Devices >

Receiver Options — MENU 6-2-0

1	Display RF Rcvr Trouble	Y
2	Alarm RF Rcvr Tamper	Y
3	Report RF Rcvr Tamper	Y
4	Alarm RF Rcvr Jamming	N
5	Report RF Rcvr Jamming	N
6	Alarm Rcvr Comms Fail	Y
7	Report Rcvr Comm Fail	Y
8	Bosch Compatble	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Device > RF Devices >

Supervision Time — MENU 6-2-1

(*** System Wide Parameter ***) [0][0][1]

Hours

Enter the supervision time for RF devices in hours (001 - 255 Hours) 000 = No Supervision.

Device > RF Devices >

RF Device Options — MENU 6-2-2

1	Display RF Tamper	Y
2	Report RF Tamper	Y
3	Report RF Low Battery	Y
4	Report Lost RF Devices	Y
5	Open Zone On Lost RF	N
6	Audible Keyfob Panic	Y
7	Report Keyfob Panic	Y
8	Keyfob Func Part On	Y

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Devices > RF Devices >

Add RF Keypad — MENU 6-2-3

Delete RF Keypad — MENU 6-2-4

View RF Device ID — MENU 6-2-5

Copyright © 2002-2022 Digflex Pty Ltd

Smart Keyfob Func — MENU 6-2-6

This menu fonfigures each button and function of smart keyfobs. Buttons 1 to 5 are single press funcions and buttons 6 to 10 are hold down functions.

Devices > RF Devices

RF Site Key — MENU 6-2-9


This menu locks RF sensors to the control panel. The default RF Site Key is the serial number of the control panel.

Devices > GSM/GPRS Module >

GSM/GPRS Status — MENU 6-5-0

This command interrogates the GSM module and displays infomration about the radio and the SIM installed. The first line is a heading which indicates the GSM module type that is installed. Typical information available includes details on the installed radio, the SIM provider and signal strength of the currently active SIM.

It should be noted that the use of SIM 2 is restricted to reporting protocols that utilise the dual sim where SIM 2 is a backup.



The following parameters will be displayed one at time on the display.

IEMI

Radio Model

Radio Firmware

Radio S/N

Provider

Signal Strength

Dual Sims Detected

Devices > GSM/GPRS Module >

GSM/GPRS Options — MENU 6-5-1

1	Display Troubles	Y
2	Report Troubles	Y
3	Delay Reporting	Y
4	Alarm On LAN Fail	N
5	Lock GSM Band	N
6	Report Device Fail	Y
7	LTE Only	N
8	Second Carrier Preferred	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Devices > GSM/GPRS Module >

APN Server Name — MENU 6-5-7

APN Server Name 1 **Digits** 32

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Devices > GSM/GPRS Module >

APN Server Name — MENU 6-5-8

APN Username 1 **Digits** 32

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Enter the appropriate name of your 3G/4G GPRS mobile network provider to connect to the public Internet. For example Telstra APN=Telstra.wap, Optus APN=yesinternet or APN = connectme, Vodafone APN=live.vodafone.com

Devices > GSM/GPRS Module >

APN Password — MENU 6-5-9

APN Password 1 **Digits** 32

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

Copyright © 2002-2022 Digflex Pty Ltd

Devices > Ethernet Module >

Module IP Address — MENU 6-6-0

0	0	0	0	0	0	0	0	0	0	0	0

This is the IP address of the module on the customers internal local area network.

Devices > Ethernet Module >

Subnet Mask — MENU 6-6-1

0	0	0	0	0	0	0	0	0	0	0	0

This can be found by running IPCONFIG on a PC connected to the clients network. Typical Subnet mask is 255.255.255.0.

Devices > Ethernet Module >

Default Gateway — MENU 6-6-2

0	0	0	0	0	0	0	0	0	0	0	0

This gateway IP address can be found by running IPCONFIG on a PC connected to the clients network.

Devices > Ethernet Module >

Module MAC Address — MENU 6-6-3

0	0	0	0	0	0	0	0	0	0	0	0

This is the hardware machine address of the module and can be found on the bar-coded sticker on the module.

Devices > Ethernet Module >

Ethernet Options — MENU 6-6-9

1	Display Faults	Y
2	Report Network Lost	Y
3	Report IP Conflict	Y
4	Report Poll Fail	Y
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Report Device Missing	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Note

See the ethernet module installation guide for more detailed explaination on installation configuring the ethernet module.

System Programming

System > Commands >

Panel Status — MENU 7-0-0

System Trouble — MENU 7-0-1

History Log — MENU 7-0-2

Factory Default — MENU 7-0-4

Template Default — MENU 7-0-5

Reserved for future use.

TimeZone Array — MENU 7-0-6

Service Mode — MENU 7-0-8

System > Clock >

Set Date And Time — MENU 7-1-0

System > Clock >

Summertime On — MENU 7-1-1

	-	-	-	-	-	-	-	-	-		
At 2:00am	Month			Week			Day				

(*** System Wide Parameter ***)

Program the month of the year (Jan – Dec), week of the month (Wk1 to Last) and day of the week (Sun To Sat). Use [←] and [→] keys to scroll cursor left and right and use [↑] and [↓] to toggle options.

System > Clock >

Summertime Off — MENU 7-1-2

	-	-	-	-	-	-	-	-	-		
At 2:00am	Month			Week			Day				

(*** System Wide Parameter ***)

Program the month of the year (Jan – Dec), week of the month (Wk1 to Last) and day of the week (Sun To Sat). Use [←] and [→] keys to scroll cursor left and right and use [↑] and [↓] to toggle options.

System > Clock >

Locale — MENU 7-1-3

(*** System Wide Parameter ***) 0 0

00 - DISABLED
01 - SYDNEY
02 - MELBOURNE
03 - BRISBANE
04 - ADELAIDE
05 - PERTH
06 - HOBART

MENU 7-1-3 programs the locale in Australia. Use [↑] and [↓] keys or enter [0] to [15] + [OK] to program.

Copyright © 2002-2022 Digflex Pty Ltd

System > Clock >

Clock Options — MENU 7-1-4

1	Display Clock Trouble	Y
2	Sync Clock To AC	Y
3	24Hr Clock	Y
4	Reserved	N
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

System > Power >

AC Options — MENU 7-3-0

1	Display AC Fail	Y
2	Report AC Fail	Y
3	Reserved	Y
4	Random AC Report 2hr	N
5	AC Fail After 1hr	N
6	Reserved	N
7	Reserved	N
8	Reserved	Y

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

System > Power >

Battery Options — MENU 7-3-1

1	Display Battery Fail	Y
2	Report Battery Fail	Y
3	Battery Test On Arming	Y
4	OK To Arm Low Battery	Y
5	Reserved	N
6	Reserved	N
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

System > Power >

Fuse Options — MENU 7-3-2

1	Display COMM+ O/Load	Y
2	Report COMM+ O/Load	Y
3	Display +12v O/Load	Y
4	Report +12v O/Load	Y
5	Display LAN O/Load	Y
6	Report LAN O/Load	Y
7	Reserved	N
8	Reserved	N

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

System > Siren >

Tone — MENU 7-4-0

Speed — MENU 7-4-1

Volume — MENU 7-4-2

(*** System Wide Parameter ***) [1][5]

Enter 0 – 15 + [OK] to program the speaker beep volume of the siren for RF keyfob and keyswitch input operation (0 = Disabled / 1 = Low – 15 = High).

System > Siren >

Siren Swinger — MENU 7-4-3

(*** System Wide Parameter ***) [0][3]

Enter 0 – 15 + [OK] to program number of times siren can sound before lockout. (0 = Unlimited).

Copyright © 2002-2022 Digflex Pty Ltd

System > TimeZones >

Name MENU 7-5-0

T	i	m	e	Z	o	n	e		2		N	a	m	e					

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

System > TimeZones >

Time MENU 7-5-1

	Start Time	Stop Time
Period 1	-- : -- : -- (HH MM SS)	-- : -- : -- (HH MM SS)
Period 2	-- : -- : -- (HH MM SS)	-- : -- : -- (HH MM SS)
Period 3	-- : -- : -- (HH MM SS)	-- : -- : -- (HH MM SS)
Period 4	-- : -- : -- (HH MM SS)	-- : -- : -- (HH MM SS)

Use [←] and [→] keys to scroll cursor left and right. Use keys [0] – [9] to enter time in hours (HH) / minutes (MM) and seconds (SS). Press [OFF] to disable the time and press [OK] to save.

System > TimeZones >

Day MENU 7-5-2

	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Hol
Period 1	N	N	N	N	N	N	N	N
Period 2	N	N	N	N	N	N	N	N
Period 3	N	N	N	N	N	N	N	N
Period 4	N	N	N	N	N	N	N	N

Enter 1 – 8 to toggle days ON/OFF, then press [OK] to save.

Note

To create a timezone for auto arming you must enter the arm time in the stop time field. For example if you want the system to arm at 5.30pm you would program 17:30:00 in the stop field.

If auto disarming is also required then you would enter the disarm time in the start time field of the same timezone period. For example if you want the system to disarm at 7.30am you would program 07:30:00 in the start field. See the full installation manual for more details.

System > TimeZones >

TimeZone Options MENU 7-5-3

1	Invert Period Logic	N
2	Master Can Edit	N
3	Reserved	N
4	Reserved	N
5	Reserved	N
6	Reserved	Y
7	Reserved	N
8	Reserved	Y

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Copyright © 2002-2022 Digflex Pty Ltd

System > Holidays >

Holiday Name — MENU 7-6-0

H	o	l	i	d	a	y		1		N	a	m	e					

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

System > Holidays >

Start Stop Dates — MENU 7-6-1

Start 12am		Stop 12am	
01	Jan	01	Jan
DD	MM	DD	MM

Use the [←] and [→] keys to move to the field then [↑] and [↓] to change. Press [OK] to save or [MENU] to exit without saving.

Note

Press [OFF] to disable the holiday.

System > System Options >

General Options — MENU 7-7-0

1	Display LAN Fail	Y
2	Report LAN Fail	Y
3	Alarm On LAN Fail	N
4	Cannot Change Own PIN	N
5	Extend LAN Fail *(Enable when using CM430S)*	N
6	Monitor Default PINs	Y
7	PIN Always Required	N
8	Display Menu Numbers	Y

(*** System Wide Parameter ***)

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

System > System Options >

Area Options — MENU 7-7-1

1	Area 1 Common	N
2	First Open Last Close	N
3	Reset Siren All Users	Y
4	Power Up As Down	Y
5	Fault ACK All Areas	Y
6	Delay Trouble Beeps	Y
7	Power Up Disarmed	N
8	Ignore Trouble On Arm	N

(*** System Wide Parameter ***)

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

System > System Options >

Keypad Idle Screen — MENU 7-7-2

(*** System Wide Parameter ***) [0][0]

00 - No Idle Screen
01 - Date And Time
02 - Time
03 - Custom Screen

Use [↑] and [↓] keys or enter 0 - 3, then press [OK] to program the keypad idle screen - Single option only.

System > System Options >

Keypad Hi/Lo Temp — MENU 7-7-3

[0][0][0] °C	[0][0][0] °C
Hi TEMP	Lo TEMP

(*** System Wide Parameter ***)

Use [↑] and [↓] Keys To Program The High / Low Keypad Monitor Temperature. Max = 50 / Min = 0.

System > System Options >

Installer Options — MENU 7-7-4

1	Report Installer	N
2	Report Prog Change	Y
3	Restrict Installer PIN	N
4	Reserved	N
5	Auto Exit Install 2hr	Y
6	Auto Exit Service 2hr	Y
7	Multi Tenant Mode	N
8	Allow Defaulting	Y

(*** System Wide Parameter ***)

Use the [↑] and [↓] keys to scroll the list of options. Select the option required, then press [ON] or [OFF] to enable or disable. A [✓] will display to indicate option set. Press [OK] to save when finished.

Copyright © 2002-2022 Digflex Pty Ltd

System > System Options >

Language **MENU 7-7-5**

0 - English
1 - Alternate Language

0

Enter digits 0 – 1 to program the language required, then press [OK] to save.

System > System Options >

Site Name **MENU 7-7-7**

1 Characters 32

M y A l a r m

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

System > System Options >

Custom Text Line 1 **MENU 7-7-8**

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.

System > System Options >

Custom Text Line 2 **MENU 7-7-9**

Use the [←] and [→] keys to scroll cursor left and right. Use the [0] – [9] keys or the [↑] and [↓] keys to scroll characters, then press [OK] to save. Press [OFF] to clear text from the current cursor position.






Figure 29: Custom Installer Baner Sample

System > System Testing >

Walk Test All Zones **MENU 7-9-0**

Battery Test **MENU 7-9-1**

Testing The System

You will need to be in programming mode before accessing the test functions listed below.

Walk Test

Use the walk test command MENU 3-9-0 to test and verify that all zones work correctly.

External Audible Test

Use MENU 4-9-0 to test and verify that all horn speakers operate. This test will sound the horn speaker for two seconds.

Internal Audible Test

Use MENU 4-9-1 to test and verify that all 12 VDC sirens operate. This test will sound the siren for two seconds.

Strobe Test

Use MENU 4-9-2 To test and verify that the strobe operates. This test will turn on the strobe until you manually stop the test.

Battery Test

Use MENU 7-9-1 to test the back-up battery that is connected to the control panel.

Communication Test

Use MENU 5-9-0 to test the reporting capability of the control panel. You can also activate a communication test by holding down the Test / Mail key on the keypad.

Copyright © 2002-2022 Digflex Pty Ltd

Installation Details

CUSTOMER NAME: _____

PHONE _____

INSTALLED BY: _____ DATE: _____

ACCOUNT N°: _____ PANEL LOCATION: _____

PANEL PHONE N°: _____ CLI ENABLED: _____

N° WIRED ZONES: _____ N° OF USERS: _____

N° RF ZONES: _____ N° OF AREAS: _____

WARRANTY EXPIRES: _____ COMMON AREA USED: _____

USER TRAINING COMPLETED BY: _____ PERSON TRAINED: _____

NOTES:

Copyright © 2002-2022 Digflex Pty Ltd

Specifications

Panel	Vision-XIP (Part Number CC715)
Voltage Input	16-18V A.C. 50-60Hz - 24VA External Power Adaptor or 220-240V A.C. to 18V A.C. 50-60Hz - 24VA Internal Transformer (Primary Power Source)
Continuous Power	1 Amp MAX (Combined power drawn from Accessory Power(+12V) Lan Power (Module LAN +) and Output Power (C+) terminals must not exceed 1 amp)
Alarm Power	4 Amp (Total with Primary and Secondary Power Sources Fitted)
Stand-by Battery	12 VDC, 7.2AH sealed rechargeable battery - Panasonic LC-P127R2P or equivalent. (Secondary Power Source) Dispose of used batteries according to the instructions.
Min Operating Voltage	10.2 VDC
Battery Charger	Pulse by pulse charger. (Note: Charge voltage can't be measured unless battery is fitted.)
Module Connection (RS485 LAN)	Max total LAN length using multi strand security cable = 300m, Max total LAN length using 2 pair twisted shielded data cable (Belden 8723) = 1200m. See the product installation manual for complete wiring instructions.
Telephone Connections	RJ-12 Socket or 4-way terminal
Temperature	0˚ to 55˚ C
Enclosure Fixing Method	**CM720 - Small Enclosure** Use appropriate fasteners capable of handling a minimum of 6kg to fix the cabinet against a sturdy surface using the mounting holes provided. **CM730 - Large Enclosure** Use appropriate fasteners capable of handling a minimum of 12kg to fix the cabinet against a sturdy surface using the mounting holes provided.
Relative Humidity	5 to 85% non-condensing.
Enclosure Dimensions:	P/N: MW720 - (W)385, (H)280, (D)90mm P/N: MW730 - (W)385, (H)520, (D)90mm
PWA Dimensions:	(W) 235, (H) 85 (H), (D) 40mm
Warranty:	3 years from date of manufacture (return to base)

The following parts are supplied with the panel

(Australian models only - content may differ in export models)

Panel Assembly Includes	1 x MW720 Metal Enclosure With Tamper	1 x Installer Reference Guide
	1 x Panel PWA	1 x Resistor Pack
	1 x User Manual	
Resistor Pack Includes	1 x Red Battery Lead	10 x 3K3 – 0.25W +/- 1% Metal Film Resistors
	1 x Black Battery Lead	10 x 6K8 – 0.25W +/- 1% Metal Film Resistors
	1 x 2-Way Shunt With Handle	1 x 3-Way Removable Terminal Block
	2 x Phillips Pan Head Zinc Plated Screws	1 x Panel Tamper Switch + Tamper Lead
	1 x Telephone Cable RJ12 6P/4C	1 x Tamper Switch Bracket
	1 x Pack PCB Mounting Clips (5 pc/pack)	1 x Product Identification Label
Available Separately	Vision-XIP Installation Manual Part Number MACC715I VisionLink (RAS) Software Part Number: SW500	

Copyright © 2002-2022 Digflex Pty Ltd

Compatible Keypads

- CP155 - External Keypad with S/C Reader
- CP156 - Slim Style External Metal Keypad with S/C Reader
- CP722 - Graphic Keypad Smart Card Reader (White)
- CP732 - Graphic Keypad Smart Card Reader (Black)
- PR113 - Internal Smart Card Reader (Black)
- PR114 - Internal Smart Card Reader (White)
- PR115 - External Smart Card Reader (Black)
- PR116 - External Smart Card Reader (White)
- CP741 - Graphic Keypad With Wi-Fi (White)

Expansion Devices

- CM195 - Multi RF Receiver Interface
- CM368 - IP Communications Module 4G GPRS Module
- CM430S - LAN to Ethernet Converter Module
- CM704 - 8/16 Zone Input Expander
- CM705 - Universal Expansion Module
- CM707 - 8/16 Piggy Back Zone Input Expander Module
- CM710 - 4-Way Relay Output Module
- CM720 - 1 Amp Power Supply Module
- CM746 - Plug On 4G GSM/GPRS Module
- CM751 - TCP/IP Interface Module
- CM760 - Real Time Clock Module
- CM797 - LAN Isolator Module
- CM796 - Wiegand to RS485 LAN Interface Module
- CM723 - LAN 5 Amp P/S Module/Dual Battery Chargers
- CM724 - LAN 5 Amp P/S Module/Dual Battery Chargers (Export Model)
- RF120 - Smart RF LAN Base Station Receiver 2-Way
- RF121 - Smart RF LAN Base Station Receiver With 4 Relay Outputs 2-Way
- RF160 - Smart RF 2 Channel Wireless Output Module

Accessories

- SW500 - VisionLink Software
- SW501 - Site Manager Onsite Administration Software
- CM435 Power Terminal Expander Module
- CM436 - Desktop Reader Interface For 3rd Party Weigand Readers
- CM438 - USB Powered Desktop Reader Interface For DF Format EM Prox Tokens
- CM439 - USB Powered Desktop Reader Interface For DF MiFare Smart Card Tokens
- CM444 Slim Style Relay Card Form C-2 Amp
- CM940 - 6 Way Programmable Relay Card
- CM910 - Combined Direct Link/Flash Programmer - USB
- CM255 - Default Key
- CP799 - Installer Service Keypad
- RF110 - Smart RF 5 Button 2-Way Keyfob
- RF110FK - Colour Fascia Kit To Suit RF110 Keyfobs
- RF112W - Smart RF Reed-HW Input+Shock+Pulse
- RF112 - Smart RF Reed-HW Input+Shock+Pulse
- RF112W - Smart RF SM Reed-HW Input+PWR Out
- RF112 - Smart RF SM Reed-HW Input+PWR Out
- PR301 - Smart Card Token With Keyring
- PR350 - ISO Smart Card
- PR365 - Adhesive Smart Card Sticker
- PR370 - Dual Smart Card and EM Format Token

Copyright © 2002-2022 Digflex Pty Ltd



DIGIFLEX PTY LTD
18 Brumby Street
Silverwater NSW 2147
AUSTRALIA
Phone: (+612) 97417000
www.digiflex.com.au

Our Vision Is Your Peace Of Mind

Made in Australia

Copyright © 2002-2022 Digiflex Pty Ltd
P/N : MACC715R